

SITE MANAGEMENT PLAN

In fulfillment of
Order WQ 2017-0023-DWQ

General Waste Discharge Requirements and Waiver of Waste Discharge
Requirements for Discharges of Waste Associated with Cannabis Cultivation
Activities



Prepared by:



Britney Newby, Environmental Scientist
britney@northpointeureka.com
(707) 798-6438

February 2019

TABLE OF CONTENTS

INTRODUCTION

SITE INFORMATION

TIER AND RISK DESIGNATION

BEST PRACTICABLE TREATMENT OR CONTROL (BPTC) MEASURES

1. Sediment Discharge Measures
 - 1.1. Site Characteristics
 - 1.1.2. Road Conditions
 - 1.1.3. Water Bodies, Stream Crossings, Riparian Setbacks
 - 1.1.4. Soil Disturbance
 - 1.2. Sediment Erosion Preventions and Sediment Capture
 - 1.2.1 Erosion Prevention BPTC Measures
 - 1.2.1.1. Roads
 - 1.2.1.2. Disturbed Areas
 - 1.2.1.3. Streams and Stream Crossings
 - 1.2.1.4. Winterization
 - 1.2.2. Sediment Capture BPTC Measures
 - 1.2.2.1. Roads, Stream Crossings, and Soil Disturbance
 - 1.2.3. Maintenance Activities – Erosion Prevention and Sediment Control
 - 1.2.3.1. Monitoring
 - 1.2.3.2. Maintenance
2. Fertilizer, Pesticide, Herbicide, and Rodenticide BPTC Measures
 - 2.1. Cultivation Product Storage, Use, and Disposal
 - 2.1.1. Storage
 - 2.1.2. Application
 - 2.1.3. Disposal and Spill Prevention/Cleanup
3. Petroleum Product BPTC Measures
 - 3.1 Petroleum Storage, Use, and Disposal
 - 3.1.1. Storage
 - 3.1.2. Application
 - 3.1.3. Disposal and Spill Prevention/ Cleanup
4. Refuse and Domestic Wastewater BPTC Measures
 - 4.1. Household Refuse and Cultivation-related Waste
 - 4.2. Residents, Employees, and Visitors
 - 4.2.1. Domestic Wastewater – Generation
 - 4.2.2. Domestic Wastewater – Disposal
5. Winterization BPTC Measures
 - 5.1. Activities and Maintenance
 - 5.1.1. Roads and Stream Crossings
 - 5.1.2. Disturbed Areas



5.1.3. Storage and Stockpiled Materials

5.1.3.1. Cultivation-related Products and Waste

5.1.3.2. Vehicles, Machines, and Petroleum Products/Waste

5.1.3.3. Stockpiled Materials

APPENDICES

Appendix A: Site Map

Appendix B: Disturbed Area Map

Appendix C: BPTC Implementation and Maintenance Schedule

Appendix D: BPTC Measure Specifications

Appendix E: References

Appendix F: Water Use Records

Appendix G: Fertilizer, Pesticide, Herbicide, and Rodenticide Product List and Records

Appendix H: Monthly BPTC Monitoring and Maintenance Records



INTRODUCTION

This Site Management Plan (SMP) has been developed to satisfy conditions of the Tier 1 enrollment requirements in the State Water Resource Control Board (SWRCB) Order No. WQ 2017-0023-DWQ (Order). The purpose of the Order is to implement the Cannabis Policy requirements for waste discharges associated with cannabis cultivation. The Policy provides a structure for managing water quality and instream flow impacts associated with cannabis cultivation. It also establishes criteria for personal use and site conditional exemptions and includes a tiered approach for permitting discharges of waste. All eligible dischargers developing land for cannabis cultivation activities are required to enroll in the program under the Order. Dischargers must implement Best Practicable Treatment or Control (BPTC) measures and submit technical and monitoring reports to assure compliance with the Order. The SMP describes how the discharger is complying with the applicable BPTC measures listed in the Policy and how they are being implemented property-wide.

SITE INFORMATION

Registrant: Chad Whitmire
P.O. Box 1722
Fort Bragg, CA 95437

Site Address: 12600 Briceland Thorn Rd.
Whitethorn, CA 95589

Parcel: Assessor Parcel Numbers: 220-191-029, 220-191-027
Lat/Long: 40.0634°, -123.9616°

Zoning: General Plan: RA5-20
Zone: U

Acres: Approximately 29.74 acres (Humboldt County WebGIS)
Disturbed Area: Approximately 0.94 acres

Location: The project site is in Whitethorn, approximately 78 miles south of Eureka. To reach the site from Eureka, take US-101 south for 63 miles to exit 642 and onto Redwood Dr. in Redway. Turn right onto Briceland Rd./ Briceland Thorne Rd. and travel 12.1 miles to Thorn Junction in Whitethorn. Turn left at the junction to stay on Briceland Thorne Rd. and take the first left onto the project site, just beyond the bridge over McKee Creek.

Site *Environmental Setting*

Description: The project site is in the Headwaters Mattole River, HUC-12 subwatershed # 180101070202, at the junction of McKee Creek and the Mattole River, both of which are salmonid-bearing streams. The center of activities is outside the stream management areas, on slopes 8-23% with southwest-facing aspect (Google Earth). The surrounding hillsides are steep (35-50%) with a majority



landcover of evergreen forest, with some deciduous and mixed forest, and a small area of scrub near Briceland Thorne Rd., as identified in the CA Dept. of Fish and Wildlife (CDFW) CA Natural Diversity Database (CNDDDB).

Waterbodies, Water Use and Storage

The main entrance road has two stream crossings (STX-1 & STX-2) at Class III drainages as it travels upslope to the residences and cultivation areas (Table 1). A 150,000-gallon rain-catchment pond is located at the western edge of the property, as identified on the site map (Appendix A) and is used for recreation and as emergency fire storage. Two wells and the water storage tanks used for irrigation are near the main cultivation area, Cultivation Area 5 (CA-5). Numerous other water storage tanks accompany the cultivation areas, some of which will be relocated to CA-5. Domestic water for the residences is supplied by a registered diversion in McKee Creek and stored in (20) 5,000-gallon storage tanks on the southern end of APN 220-191-029 as part of the Sanctuary Forest Inc. Storage and Forbearance Program. A separate Notification of Lake or Streambed Alteration (LSA) has been filed with CDFW for the domestic water diversion system and another for other jurisdictional items.

Cultivation Areas

As part of the Humboldt County planning process, the discharger is in the process of reducing, relocating, and remediating cultivation sites. Four cultivation areas (CA-1 to CA-4) are being relocated uphill to the environmentally superior CA-5 on APN 220-191-027 (Appendix A & B). The disturbance area for each cultivation area is listed in Table 1. Cultivation Area 1 (CA-1) is adjacent to the lower residence and will be replaced with a domestic vegetable/fruit garden, the greenhouse at Cultivation Area 2 (CA-2) will be used for a domestic vegetable garden, Cultivation Area 3 (CA-3) will have one terrace remediated and the other planted with fruit trees, and Cultivation Area 4 (CA-4) will be entirely remediated.

TIER AND RISK DESIGNATION

The Cannabis Policy provides criteria for evaluating threats to water quality for cannabis cultivation sites based on three site characteristics: proximity to water body, total disturbed area, and slope of the disturbed area. Based on the criteria and site characteristics the subject property is designated as a **Tier 1**. The total disturbed area is 0.94 acres (Table 1).

Table 1: Disturbed Area Size, Slopes, and Setbacks

Disturbed Area Type	Area (ft ²)	Disturbed Area Slope	Distance to Water Body (ft.)	Water Body Type
Cultivation Area 1	1,995	8%	210	Class I
Cultivation Area 2	2,710	10%	340	Class I
Cultivation Area 3	4,570	16%	100	Class III
Cultivation Area 4	2,725	12%	215	Class III
Cultivation Area 5	12,850	12%	210	Class III



Skid Roads	8,358	8-15%	100-150	Class III
Residence	768	12%	210	Class III
Drying/Storage Shed	320	17%	230	Class I
Drying/Curing Building	560	7%	155	Class III
Conex Box & Dumpster	200	3%	115	Class III
Water Storage Tanks	1,510	2-20%	150-275	Class III
Rain-catchment Pond	4,500	2%	240	Class I
Spent Soil	25	10%	250	Class III
Total Disturbed Area	41,091 ft² (0.94 acres)			

The main entrance road was constructed prior to cultivation activities and is maintained according to the guidance provided by the *Handbook for Forest, Ranch, and Rural Roads* (“Road Handbook”) by Pacific Watershed Associates. Thus, the area of the road network is not included in the total disturbed area. See the disturbed area map in Appendix B for specific areas included in the disturbed area.

In addition to a tier designation, a risk designation is assigned based on the slope of the disturbed areas and proximity to a waterbody. Based on these parameters, the subject property is designated as a **Low Risk**. The total disturbed area of 0.94 acres remains outside of the riparian setback requirements and on slopes less than 30 percent.

BEST PRACTICABLE TREATMENT OR CONTROL (BPTC) MEASURES

BPTC measures are being utilized as part of the road maintenance program to protect water quality. The *Construction Site Best Management Practices Manual* by the CA Department of Transportation (Caltrans) is referenced for the correct installation, maintenance, and monitoring of all applicable erosion control and sediment capture BPTC measures.

All straw mulch must be free of noxious weeds and all seed/plants must be non-invasive. A list of prohibited species can be found in the CA Invasive Plant Council’s database. Erosion control measures shall not include synthetic monofilament netting, including photo- and biodegradable plastic netting. All netting shall be made of jute, coir fiber, hemp, or another product without welded weaves.

A schedule of BPTC measures to be implemented and maintained throughout the site is shown in Appendix C. Table 2 below and Appendix D include Map I.D. specifications for BPTCs.

Table 2. Map I.D.s for BPTC measures

Map I.D.	BPTC Measure
RD1.3	Outsloped Roads w/Inboard Swale
RD1.4	Outsloped Road
RD1.8	Rolling Dip
RD1.10	Water Bars
RD1.14	Road Surface Upgrade
RD1.17	Road Closure
EC1.1	Jute Mat Blanket
EC1.3	Outlet Protection
EC1.4	Stockpile Management
SS-6	Straw & Mulch
SS-10	Outlet Protection
SC1.1	Check Dams
SC1.3	Fiber Rolls

1. SEDIMENT DISCHARGE BPTC MEASURES

1.1. SITE CHARACTERISTICS

1.1.1. SITE MAP

The site map shows all relevant site features: streams, stream crossings, storage areas, roads, buildings, domestic wastewater treatment system, cultivation areas, and other disturbed areas related to cultivation activities. Erosion prevention and sediment control BPTC measures are identified on the site map (Appendix A).

1.1.2. ROAD CONDITIONS

The main entrance road receives approximately four daily vehicle trips in the peak season (May - October) and two vehicle trips in the winter season. The main access road is rocked and generally has a slope > 20%. Much of the road is outsloped to spread out the surface runoff. A few inboard ditches are full of debris, causing runoff to concentrate and thus minor rills to form across the road surface. Currently, road maintenance activities consist of redefining and clearing inboard ditches of debris (**Map ID: RD1.3**) and installing temporary water bars (**RD1.10**) on the main road for the winter season. Additional road maintenance is prescribed in section 1.2.1.

1.1.3. WATER BODIES, STREAM CROSSINGS, RIPARIAN SETBACKS

Stream crossing 1 (STX-1) is a 24" corrugated plastic pipe (CPP) within a Class III stream. Stream crossing 2 (STX-2) is a 24" CPP within a Class III stream. Both stream crossings were installed on gradient and are appropriately sized. Structural and biological BPTC measures (rip rap, straw) have been installed at the inlets/outlets to control erosion. In addition, a 150,000-gallon rain-catchment pond exists on the property near Thorn Junction and is being used as emergency storage. The spillway is rocked and connects to the top of a Class III drainage. The dam will need to be raised, though, so that there is at least 2 feet of freeboard. The two

stream crossings and pond spillway will be maintained as required in the Lake or Streambed Alteration Agreement (LSAA) with the California Department of Fish and Wildlife (CDFW). An LSA Notification has been filed and a Final Agreement will be made after CDFW review.

All structures and cultivation areas currently meet setback requirements in the Order.

1.1.4. SOIL DISTURBANCE

The site has no areas of active soil disturbance. All historic graded areas are stable and vegetated, and there are no active slides or earth movement on site. However, reconfiguration and remediation of cultivation areas into one upper site is planned per the Humboldt County permitting process. Earthmoving will be involved in the remediation of cultivation flats and in the obliteration of two road segments (**RD1.17**). All appropriate BPTC measures will be utilized during and after the construction process.

1.2. SEDIMENT EROSION PREVENTION AND SEDIMENT CAPTURE

1.2.1. EROSION PREVENTION BPTC MEASURES

1.2.1.1. ROADS

Sections of the access road will be outslopped (**RD1.4**) to disperse road runoff and rolling dips (**RD1.8**) will be installed at bends and uphill of inflection points where the runoff is crossing the road. The road surface will be improved (**RD1.14**) with angular rock to prevent further surface erosion. A steep skid road is slated to be removed and requires BPTC measures to be installed. A rolling dip (**RD1.8**) will be constructed on the road during the dry season, but in the interim, fiber rolls (**SC1.3**) and check dams (**SC1.1**) on the inboard ditch will control the sediment. In addition, the upslope road runoff will be conveyed past the top of the skid road and onto a stable, vegetated slope by using fiber rolls (**SC1.3**).

Inboard ditches that are filled in with debris will be cleared and redefined (**RD1.3**) so that runoff stays in the inboard ditch. The inlets of two Ditch Relief Culverts (DRC) will be cleared out as well to prevent further erosion and sedimentation. The culvert outlets discharge onto stable, vegetated, or armored slopes (**EC1.3 & SS-10**) and not into natural watercourses.

Earthwork erosion prevention measures for the roads will be implemented during the dry summer months. Minor interim and winterization measures will be utilized during the rainy season to prevent further erosion. The road construction standards described in the "Road Handbook" will be adhered to for all road improvements. See Appendix C for the Schedule of BPTC Implementation and Maintenance.

1.2.1.2. DISTURBED AREAS



All exposed soil in disturbed areas have been seeded and mulched with straw (**SS-6**) and existing live mulch will be maintained. Structural and soil stabilizing measures have been installed: fillslopes have fiber rolls (**SC1.3**) and silt fences along the perimeter and cutbanks have been covered with jute mat (**EC1.1**). Additional jute mat will be added to cutbanks that are exposed. Any areas for planned disturbance will be surveyed for sensitive botanical species, communities, and wildlife prior to construction and appropriate BPTC measures will be utilized to prevent erosion.

1.2.1.3. STREAMS AND STREAM CROSSINGS

The two stream crossings on site have low diversion potential and are in locations where the road is nearly flat. All future stream crossing work will be designed according to the standards in CDFW's *CA Salmonid Stream Habitat Restoration Manual*.

Stream crossing inspection and maintenance, such as the removal of debris, will be regularly conducted throughout the year, and after a significant storm event (0.5 in/day or 1 in/7 days of rain). All cultivation operations comply with setbacks from streams and riparian areas. The existing riparian vegetation has been preserved and the buffer width maintained. Biological or structural BPTC measures will be implemented depending on the requirements in the Final LSAA.

1.2.1.4. WINTERIZATION

Winterization measures will be implemented annually by November 1st and interim erosion prevention BPTC measures will be utilized as needed throughout the year. To prevent erosion and sediment transport, numerous measures for soil stabilization, runoff management, erosion and sediment prevention/retention are utilized throughout the seasonally dry period and prior to the onset of winter. Section 5 "Winterization BPTC Measures" has more information on proposed actions to protect water quality in the winter season.

1.2.2. SEDIMENT CAPTURE BPTC MEASURES

1.2.2.1. ROADS, STREAM CROSSINGS, AND SOIL DISTURBANCE

Minor sediment control measures including runoff management and sediment barriers will be used to stabilize the roads and cultivation flats. Existing fiber rolls (**SC1.3**), silt fences, and other physical sediment control measures will be maintained. Exposed cutbanks may also be hydroseeded and covered with jute mat (**EC1.1**).

During road construction and maintenance activities, sediment control devices (e.g. fiber rolls, gravel bag berms) will be installed around culvert inlets to prevent sediment transport.



Stockpiled materials (**EC1.4**) for construction and road maintenance will be stored in stable locations and contained using appropriate BPTC measures. Cement blocks surround a spent soil/compost pile on the upper cultivation flat. Garden beds are covered in plastic and walkways/disturbed areas are stabilized with straw (**SS-6**) and living mulch. See Appendix C for the schedule of all sediment control BPTC measures being employed on site.

1.2.3. MAINTENANCE ACTIVITIES – EROSION PREVENTION AND SEDIMENT CAPTURE

1.2.3.1. MONITORING

All long-term and interim erosion prevention and sediment capture BPTC measures that have been implemented will be monitored for effectiveness on a monthly basis at a minimum (Table 1.2.3.1). Any vegetation planted on previously disturbed areas will be monitored for success and replanted if necessary. The cultivator will monitor erosion and sediment control measures during and after each storm event that produces at least 0.5 in/day or 1 in/7 days of precipitation. In addition, winterization measures that are implemented will be monitored for effectiveness (inspected during the first major winter storm event) before the site is closed for the winter. See Appendix H for a log of monthly BPTC monitoring and maintenance records.

Table 1.2.3.1. BPTC Effectiveness Monitoring

Observations	Description	Monitoring Frequency
Erosion Prevention and Sediment Capture Maintenance	Report activities for maintaining the effectiveness of erosion prevention and sediment retention/capture measures	Monthly
Active Erosion	Report any indications of soil erosion	Monthly
Surface Water Runoff Maintenance	Report the conditions of any surface water (stormwater, irrigation) and include the location, source of runoff, duration	Monthly

1.2.3.2. MAINTENANCE

Year-round maintenance of all erosion prevention and sediment capture measures is required. All existing measures shall be maintained, repaired, or replaced as needed. Exotic or invasive species found in revegetated or disturbed areas shall be removed. Remaining exposed soil shall be reseeded/revegetated and have 2-4” of weed-free mulch (**SS-6**) reapplied. Any captured sediment in inboard ditches/drainageways, culvert outfalls, or against silt fences/fiber rolls will be removed and stabilized on a designated flat area. The sediment may be used for site improvement where it will not threaten water quality. Interim measures for sediment retention, such as mulching and installing fiber rolls, require more



regular monitoring and maintenance. See Appendix H for a log of monthly BPTC monitoring and maintenance records.

2. FERTILIZER, PESTICIDE, HERBICIDE, AND RODENTICIDE BPTC MEASURES

2.1. CULTIVATION PRODUCT STORAGE, USE, AND DISPOSAL

2.1.1. STORAGE

Fertilizers and pesticides are being stored separate from petroleum products in a 16' x 20' storage shed (Appendix A). At the end of the season, any unused liquid products are stored in secondary containment within the shed and applied the following year. Soil and fertilizers may temporarily be stored in or near the covered greenhouses prior to being applied. No rodenticides are currently being used on site.

Appropriate BPTC measures are being utilized when storing, handling, mixing, applying, and disposing of all fertilizers, pesticides, herbicides, and rodenticides. Each year an inventory is conducted prior to the beginning of the grow season and necessary products are delivered to the site as needed. See Appendix G for a list of fertilizers and pesticides/herbicides used on site.

2.1.2. APPLICATION

Mixing of compost tea in small storage tanks is conducted in a designated area where the mix will not enter surface waters. The compost tea is intermittently applied via hand-watering at agronomic rates during all stages of growth. Watering is otherwise done with drip emitters. The soil is amended each year at the start of the growing season and as needed through the summer. Spent soil is composted in a designated location (Appendix B). The application of any agricultural chemical products will be conducted according to the manufacturer's recommendation.

2.1.3. DISPOSAL AND SPILL PREVENTION/CLEANUP

Refuse and recycling is being kept in a roll-off dumpster to prevent surface water contamination and wildlife intrusion. The dumpster is located near the entrance of the property. Excess soil not slated to be reused or mulched will be disposed of properly along with other cultivation products, and the disturbed area will be seeded and covered with straw (**SS-6**) to prevent erosion. Spent product containers are carefully transferred from the mixing area to the refuse area. A spill kit with plenty of sorbent pads is kept on site in the event of a spill. All refuse, empty product containers, and other recycling are hauled off site every 1-3 months to the Eureka or Willits waste management facility.

3. PETROLEUM PRODUCT BPTC MEASURES

3.1. PETROLEUM STORAGE, USE, AND DISPOSAL



Table 3.1. Petroleum Product List, Storage, and Use

Petroleum Product	Delivery Period	Storage Method	Use Type
Gasoline	As needed throughout the growing season (April - October)	500-gallon metal petroleum storage tank inside storage shed	Generator
Propane Tank	As needed throughout the year	(2) 250-gallon metal propane tanks	Heating/cooking for the house
Lubricants	As needed throughout the year	In storage shed within secondary containment	Equipment maintenance

3.1.1 STORAGE

The discharger has a 10' x 12' generator shed with a concrete floor that houses the diesel generator, a 500-gallon petroleum storage tank, 5-gal gas cans, oil containers, and other hazardous materials (see site map in Appendix A). The generator needs a drip pan and the petroleum storage tank needs secondary containment. A 250-gallon propane tank is at each residence and they are serviced by a licensed professional approximately twice per year. Vehicles and machines are regularly monitored for leakage and when not in use are being stored in a location outside riparian setbacks. Additional fuel is safely transported to the site in a transfer tank as needed.

3.1.2. APPLICATION

Fueling and maintenance of the generators, cars, and other machines is being conducted in a designated area that prohibits discharge to waters of the state.

3.1.3. DISPOSAL AND SPILL PREVENTION/CLEANUP

Special care is taken when transporting and handling all petroleum products. Spill prevention/cleanup BPTC measures are being utilized; a spill kit with plenty of sorbent pads is kept on site in the event of a spill. Spent petroleum products and related trash are kept in secondary containment, specifically for hazardous waste, before being transferred to the waste management facility.

4. REFUSE AND DOMESTIC WASTEWATER BPTC MEASURES

4.1. HOUSEHOLD REFUSE AND CULTIVATION-RELATED WASTE

All refuse generated on site will be temporarily stored in a designated area in or near each residence where it will prevent wildlife intrusion and not leach into waters of the state (Appendix A). The refuse/ recycling is then stored in large roll-off dumpster before being taken to the waste management facility. Cultivation-related organic waste and spent soil is composted in a designated area on the cultivation flat and stabilized with stabilized with cement blocks and straw bales. Every 1-3 months, all refuse and non-organic cultivation



waste are then transported to the Eureka or Willits waste management facility.

4.2. RESIDENTS, EMPLOYEES, AND VISITORS

Approximately 2-4 residents are on site throughout the year and there are currently no employees. Occasional visitors and family members come to the site.

4.2.1 DOMESTIC WASTEWATER – GENERATION

The households produce greywater from the kitchen sinks and showers, and blackwater from the toilets.

4.2.2 DOMESTIC WASTEWATER – DISPOSAL

There are (2) unpermitted septic systems (Appendix A) at each residence. The property owner is in the process of completing the site analysis and design work and applying for septic permits. The septic systems should receive approval within 2 years (October 2021). The cultivator shall ensure that substances that are hazardous to fish and wildlife (e.g. trash, paint, concrete washings, treated wood) are used, stored, and disposed of appropriately.

5. WINTERIZATION BPTC MEASURES

5.1. ACTIVITIES AND MAINTENANCE

5.1.1 ROADS AND STREAM CROSSINGS

Appropriate erosion prevention and sediment control measures will be installed, maintained, and monitored for effectiveness prior to the winter season. Road work requiring heavy machinery, such as outsloping, shall be conducted only during the dry season, unless the cultivator is authorized by an agency with jurisdiction to make emergency repairs. Winterization of the main access road includes temporary and long-term runoff management and soil stabilization measures, such as the clearing of inboard ditches (**RD1.3**), installing check dams (**Sc1.1**) and water bars (**RD1.10**), and stream inlet protection. All winterization BPTC measures will be monitored and maintained prior to site closure for the winter. Culverts will be inspected for erosion or clogging prior to and after a significant storm event. Any debris and sediment found to be clogging culverts, inlets/outlets, or drainageways will be removed and appropriately stored, reused, or disposed of.

5.1.2. DISTURBED AREAS

Prior to the rainy season, areas that have exposed soil shall be seeded/hydroseeded and mulched (**SS-6**) to prevent erosion and sediment delivery to a waterbody. Any revegetation shall take place at the onset or at the end of the precipitation season to ensure establishment. Exposed slopes shall have linear sediment controls (i.e. fiber rolls or silt fences) installed and maintained to interrupt sheet flow lengths. All disturbed areas will be inspected for potential and



active erosion issues. Such sites will be repaired/controlled as needed using appropriate BPTC measures.

5.1.3. STORAGE AND STOCKPILED MATERIALS

5.1.3.1. CULTIVATION-RELATED PRODUCTS AND WASTE

All fertilizers, pesticides, herbicides, and rodenticides need to be stored where they will not enter surface waters or pose a threat to wildlife. The cultivator will have all liquid products stored in secondary containment and stored along with all other cultivation-related products, protected from the elements. Waste associated with cultivation will be removed from the site and taken to the Eureka or Willits waste management facility at the closing of operations for the winter.

5.1.3.2. VEHICLES, MACHINES, AND PETROLEUM PRODUCTS/WASTE

Prior to winter, any remaining vehicles or machines on-site will be stored out of the elements where any potential leaks will not enter surface waters or pose a threat to wildlife. The generator shed will also be locked to prevent wildlife intrusion. Petroleum products will be kept in compatible secondary containment within their own storage container. Any spent petroleum containers and related trash will be removed and appropriately disposed of at the Eureka or Willits waste management facility.

5.1.3.3. STOCKPILED MATERIALS

Appropriate BPTC measures shall be used for all stockpiled materials (**EC1.4**) that have the potential to migrate to surface waters or that may be hazardous to wildlife. Stockpiled materials include bark, sawdust, potting soil, amendments, rock, compost, treated wood, polytube and other irrigation equipment, greenhouse plastic sheeting, and any other materials used for cultivation and site development, improvement, and management. They shall be stabilized in an upland area, covered, and/or stored in a storage shed/container prior to the onset of the rainy season.



BPTC IMPLEMENTATION & MAINTENANCE SCHEDULE

Type		Measures	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sep	Oct	Nov	Dec	
EROSION PREVENTION	Physical	Runoff Management	Diversions - Perimeter Dikes, Swale, Check Dams, Water Bars, Rolling Dips				Conveyance - Lined Waterway, Grade Stabilization Structures								
		Soil Stabilization	Non-Vegetative Soil Cover - Mulching, Soil Tackifiers, Slope Protection, Riprap, Fiber Rolls and other Rolled Erosion Control Products (RECP), Plastic Cover, Surface Roughening												
		Structural	Retaining Wall, Sediment Basins/Traps, Silt Fences; Armoring and Velocity Dissipators; Inlet, Outlet, and Streambank Protection/Stabilization												
	Biological	Runoff Management	Diversion/Conveyance - Grassed Waterway												
		Soil Stabilization	Temporary/Permanent Seeding, Hydroseeding, Topsoiling, Live Mulching, Vegetation Preservation/Replacement												
		Biotechnical	Biotechnical - Wattling, Brush Layering, Branch Packing, Live Cribwalls, Live Fascines, Live Plantings, Vegetated Streambank Protection, Vegetated Gabions												
SEDIMENT CONTROL	Physical	Runoff Management	Sediment Conveyance - Lined Drainageways												
		Sediment Retention	Retaining Wall, Sediment Basins/Traps - Pipe Outlet Traps, Embankment and Debris Basins, Settling Ponds, Rock Dams												
		Sediment Barriers	Straw Bale Dikes, Drain Inlet Filters, Gravel Bag Berms, Fiber Rolls, Silt Fences, Turbidity Curtain												
		Mud and Dust Control	Construction Entrance and Road Stabilization, Dust Control, Waterway Crossing												
	Biological	Soil Stabilization	Hydroseeding, Vegetated Outfalls												
INTERIM EROSION & SEDIMENT CONTROL MEASURES		Installed and Maintained as Needed													



CULTIVATION ACTIVITIES SCHEDULE

Highlight or check off the months when the following activities will take place.

BPTC IMPLEMENTATION & MAINTENANCE SCHEDULE

Type		Measures	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sep	Oct	Nov	Dec
EROSION PREVENTION	Physical	Runoff Management Diversions - Perimeter Dikes, Swale, Check Dams, Water Bars, Rolling Dips Conveyance - Lined Waterway, Grade Stabilization Structures												
		Soil Stabilization Non-Vegetative Soil Cover - Mulching, Soil Tackifiers, Slope Protection, Riprap, Fiber Rolls and other Rolled Erosion Control Products (RECP), Plastic Cover, Surface Roughening												
		Structural Retaining Wall, Sediment Basins/Traps, Silt Fences; Armoring and Velocity Dissipators; Inlet, Outlet, and Streambank Protection/Stabilization												
	Biological	Runoff Management Diversion/Conveyance - Grassed Waterway												
		Soil Stabilization Temporary/Permanent Seeding, Hydroseeding, Topsoiling, Live Mulching, Vegetation Preservation/Replacement												
		Biotechnical Biotechnical - Wattling, Brush Layering, Branch Packing, Live Cribwalls, Live Fascines, Live Plantings, Vegetated Streambank Protection, Vegetated Gabions												
SEDIMENT CONTROL	Physical	Runoff Management Sediment Conveyance - Lined Drainageways												
		Sediment Retention Retaining Wall, Sediment Basins/Traps - Pipe Outlet Traps, Embankment and Debris Basins, Settling Ponds, Rock Dams												
		Sediment Barriers Straw Bale Dikes, Drain Inlet Filters, Gravel Bag Berms, Fiber Rolls, Silt Fences, Turbidity Curtain												
		Mud and Dust Control Construction Entrance and Road Stabilization, Dust Control, Waterway Crossing												
	Biological	Soil Stabilization Hydroseeding, Vegetated Outfalls												
INTERIM EROSION & SEDIMENT CONTROL MEASURES		Installed and Maintained as Needed												



Table of Contents

RD1.1 Modified Low Water Rock Ford

RD1.2 Fords

RD1.3 Outsloped Roads w/ Inboard Swale

RD1.4 Outsloped Road

RD1.5 Inslope Road

RD1.6 Thru Cut Road

RD1.7 Critical Dips

RD1.8 Rolling Dip

RD1.9 Grading Unpaved Road Surfaces

RD1.10 Water Bars

RD1.11 Ditch Relief Culverts (DRC)

RD1.12 Stream Crossing Installation

RD1.13 Drainage for Unpaved Roads

RD1.14 Road Surface Upgrade

RD1.15 Routing and Location

RD1.16 Understanding Road Removal

RD1.17 Road Closure

EC1.1 Jute Mat Blanket

EC1.2 Culvert Outlet Energy Dissipater

EC1.3 Outlet Protection

EC1.4 Stockpile Management

SS-6 Straw and Mulch

SS-7 Geotextiles, Mats, Plastic Covers, and Erosion Control Blankets

SS-10 Outlet Protection

SS-11 Slope Drains


SC1.1 Check Dams

SC1.2 Sediment Basin

SC1.3 Fiber Rolls

Road BMP Resources


RD-1.1 MODIFIED LOW WATER ROCK FORD



NOTE: IF ROCK IS USED FOR THE ARMORED SURFACE, PLACE GEOTEXTILE FABRIC AMOCO 2002, OR EQUAL PRIOR TO ROCK INSTALLATION.

ARMORED SURFACE: 12" OF 6" MINUS RIVER RUN ROCK
 RIP-RAP: 12" OF TYPE NO. 1 BACKING ROCKS (0-5% 200 LBS, 50-100% 75 LBS, AND 90-100% 25 LBS)

PLAN VIEW



SECTION A-A

RD-1.2 FORDS

DESCRIPTION

Fords work well on small to medium sized streams where there is a stable stream bottom and traffic is light. However, "construction" of fords and other unimproved stream crossings on well traveled roads should be avoided where water is flowing because of their potential to impact water quality. In certain situations, where flash floods, high seasonal flood peaks or floating debris are problems, fords may be a practical answer for crossing a poorly incised, shallow stream.

BEST MANAGEMENT PRACTICES

- Fords in flowing streams, called "wet fords," are typically composed of streambed gravels, fill, or concrete structures built in contact with the streambed so that vehicles can cross the channel (Figure 1).
- Fords should be designed to allow low summer flows seep through the fill, and high water discharges flow over the top (Figure 2).
- Paving fords across flowing streams may be necessary to maintain water quality if there is to be regular traffic. Paving consists of a concrete, slightly dish-shaped slab across the watercourse, and a discharge apron or energy dissipater on the downstream side to prevent scour during high flows.
- On small, poorly incised, ephemeral or intermittent streams a ford may be needed if there is insufficient channel depth to install a culvert. In fact, a rock lined rolling dip with a rock apron face is generally desirable to permanent culverts on these swales and small watercourses. Fords have the advantage, over culverted fills, of never plugging.
- Fords on small streams should be rock armored to prevent erosion of the road surface and fill during periods of runoff. The fill face on the downstream side of the fill can either be protected with rock armor or fitted with a large overside drain (berm drain) to prevent erosion (Figure 3).
- Unimproved fords, which consist of a stream channel that has been filled with a substantial quantity of soil and left unprotected by armor or surfacing is a hazard to water quality and should not be constructed.

Figure 1. Wet ford on Class II perennial stream. Clean rock aggregate has been imported for the travelling surface and coarse rock armor protects the outer edge of the road bed. It is important that rock aggregate used in a ford be large enough to resist transport during winter flows. Fords should not be used if high winter flows would cut off access to inspect and maintain drainage structures further out the road. From Weaver and Hagans (1994).






Figure 2. Typical ford stream crossing. From CDFG (2006).




Figure 3. Typical armored stream crossing. From CDFG (2006).




Figure 4. Design elements of a typical armored fill crossing. Note: where geotextile fabric may interfere with passage of amphibians in any Class 2 or 3 crossing, bury geotextile fabric with at least 6 inches of rock. Do not expose geotextile fabric in the bed of fish-bearing stream channels. From CDFG (2206).


Source Material for Road BMP RD-2.7 Fords

2006. California Department of Fish and Game. Part X - Upslope Erosion Inventory and Sediment Control Guidance, California Salmonid Stream Habitat Restoration Manual.

1994. Weaver W.E. and D.K. Hagans. Handbook for Forest and Ranch Roads. Mendocino County Resource Conservation District

RD-1.3 OUTSLOPED ROAD W/ INBOARD SWALE


NOTE: ALL ROAD WIDTHS TO BE 12' MINIMUM AND ROCKED/REINFORCED WITH 2" MINIMUM AGG. BASE FROM ON SITE SOURCE



RD-1.4 OUTSLOPED ROAD

NOTE: ALL ROAD WIDTHS
TO BE 12' MINIMUM AND
ROCKED/REINFORCED WITH
2" MINIMUM AGG. BASE
FROM ON SITE SOURCE


NOTE: ALL ROAD WIDTHS
TO BE 12' MINIMUM



RD-1.5 INSLOPE ROAD


NOTE: ALL ROAD WIDTHS
TO BE 12' MINIMUM AND
ROCKED/REINFORCED WITH
2" MINIMUM AGG. BASE
FROM ON SITE SOURCE

NOTE: ALL ROAD WIDTHS
TO BE 12' MINIMUM



INSLOPE SECTION

RD-1.6 THRU CUT ROAD



NOTE: IF ROCK IS USED FOR THE ARMORED SURFACE, PLACE GEOTEXTILE FABRIC AMOCO 2002, OR EQUAL PRIOR TO ROCK INSTALLATION.

ARMORED SURFACE: 12" OF CLASS 2 AGGREGATE BASE (3" MINUS, WELL GRADED AND LESS THAN 5% CLAYS)

RD-1.7 CRITICAL DIPS

DESCRIPTION

A critical dip is a rolling dip constructed on or close to the down-road hinge-line of a stream crossing, displaying a diversion potential. Build a critical dip at all stream crossings in order to prevent stream diversions when a culvert plugs and water flows out onto the road. Construction may be similar to Road BMP RD-1.8 Rolling Dips.

BEST MANAGEMENT PRACTICES

- Stream crossings should be constructed to prevent diversion of flood overflow if the culvert were to become plugged. This can be done by designing the road to dip into and out of the stream at the crossing site or by installing a broad rolling dip on the down-road side of the crossing. This will allow the overflow to be directed back into the natural stream channel (Figure 1).
- Critical dips should be designed to handle the 100-year flow event for the stream it is installed at.
- Road surface and fill slopes at the critical dip should be rocked or otherwise stabilized.
- Must be deep enough that it is not obliterated by normal grading, but not so deep that it is difficult to negotiate or a hazard to normal traffic (Table 1).
- See Road BMP RD-1.8 Rolling Dips for more details.

Road grade %	Upslope approach (distance from up-road start of rolling dip to trough) (ft)	Reverse grade (distance from trough to crest) (ft)	Depth below average road grade at discharge end of trough (ft)	Depth below average road grade at upslope end of trough (ft)
<6	55	15-20	0.9	0.3
8	65	15-20	1.0	0.2
10	75	15-20	1.1	.01
12	85	20-25	1.2	.01
>12	100	20-25	1.3	.01

Table 1. Table of rolling dips dimensions. Design principles apply to critical dip. From CDFG (2006).





Figure 1. Install critical dips to prevent diversion prevention at stream crossings. Critical dips should be designed to handle the flow from a 100-year storm event. From CDFG (2006).

Source Material for Road BMP 2.9 Critical Dips

2006. California Department of Fish and Game. Part X - Upslope Erosion Inventory and Sediment Control Guidance, California Salmonid Stream Habitat Restoration Manual.

2004. FishNet 4C. Guidelines for Protecting Aquatic Habitat and Salmon Fisheries for County Road Maintenance.

RD-1.8 ROLLING DIP



ARMORED SURFACE: 12" OF CLASS 2 AGGREGATE BASE (3" MINUS, WELL GRADED AND LESS THAN 5% CLAYS)
 RIP-RAP: 12" OF TYPE NO. 1 BACKING ROCKS (0-5% 200 LBS, 50-100% 75 LBS, AND 90-100% 25 LBS)

NOTE: PORTIONS ARE EXAGGERATED FOR CLARITY

ROLLING DIP DETAIL
 NOT TO SCALE

ROAD GRADE (%)	SOIL ERODIBILITY EROSIIVE SOILS (FT)
0-3	250
4-6	160
7-9	130
10-12	115
12+	100

RD-1.9 GRADING UNPAVED ROAD SURFACES

DESCRIPTION

Good maintenance practices on unpaved road surfaces prevent roadway erosion, deterioration or failure; helps with sediment and dust control, and provides a safe roadway surface for the traveling public.

BEST MANAGEMENT PRACTICES

- Fit grading to the surrounding terrain.
- Blade and compact a smooth surface and compact loose soils as needed.
- Crown or slope the road to avoid ponding or concentration of runoff. Outslope all roads where possible and safe.
- Preserve existing vegetation to the greatest extent feasible.
- Minimize the length and steepness of slopes.
- Maintain natural drainage patterns in watershed.
- Preserve or improve surface drainage in the vicinity of the road.
- Disconnect road drainage features from watershed hydrology.
- Make sure drainage is self-maintaining.
- Keep runoff velocities low, using energy dissipating control measures.
- Minimize amount of road-related sediment that gets into watercourses.
- Prevent dust abatement chemicals from getting into watercourses or riparian areas.

SEASONAL CONCERNS

- Perform routine road surface maintenance during the dry season. Avoid working in wet conditions and during the wet season (October 15- April 15), except for emergencies. Disturbed soil combined with rainfall, greatly increase the risk of exposed sediment runoff into streams.
- Inspect roads and associated drainage facilities for signs of erosion or deterioration at least twice annually with at least one inspection during or after first storm events of the season with additional follow-up for severe storm events. Inspect all road and drainage facilities after a large storm event. Note locations of road surfaces, drainage features, cutslopes and fillslopes that appear to be failing and contributing sediment to streams in order to prioritize maintenance or repair.

SPOILS AND SIDECASTING

- Avoid sidecasting of soil in all cases where it could be delivered into a watercourse, riparian area, roadside ditch or storm drain. In some instances, under the following guidelines (Table 1), sidecasting is allowable given remote distances from spoils storage sites. In these cases, the setback distance required depends on slope and vegetation. The presence of vegetation helps to slow the travel of sediment downslope, so good judgment is needed to assess the situation. *Do not sidecast at all* if the slope is sparsely vegetated and it appears that sediment will travel with rain runoff into a stream or estuary system, even if setback distances are applied. On slopes of 5:1 (20% gradient) or less, sidecasting is allowed beyond 150 feet of a watercourse, stream crossing, riparian area, roadside ditch or storm drain. On 2:1 slopes (50%) or less, sidecasting is allowed beyond 300 feet of a watercourse, stream crossing, riparian area, roadside ditch or storm drain. On slopes greater than 2:1, typically sidecasting is *not recommended*, however there may be rare instances on slopes greater than 2:1 where sidecasting is acceptable given very long distances from waterbodies and good vegetative cover. Seek advice from local fisheries agency staff when in doubt. Avoid concentrating sidecasting repeatedly in the same place. Never sidecast large amounts of soil from major landslides.

- Temporary spoils stockpiles should be located in areas that are relatively level; relatively free of vegetation and away from streams and wetlands areas (see Erosion Control BMP EC-1.5 Stockpile Management). The primary concern is to keep stockpiled materials from eroding into stream or wetland systems. Apply erosion control BMPs when needed. Do not place temporary spoils piles at the top of unstable slopes or at the edges of slopes where water will carry sediment into watercourses. Remove temporary stockpiles to permanent disposal locations before the rainy season. If emergency work is conducted during the rainy season, remove stockpile as soon as feasible and before the next rain storm.

SLOPE GRADIENT	DISTANCE FROM WATERCOURSE, STREAM CROSSING, RIPARIAN AREA, ROADSIDE DITCH, STORM DRAIN	SIDECASTING RULE
Any slope	Appears that sediment will travel with rainwater into watercourse.	Not allowed
5:1 (20%) or less	150 feet or more	Allowed using good judgment
2:1 (50%) or less	300 feet or more	Allowed using good judgment
Greater than 5:1 (50%)	Vegetated slope long distance from watercourse	Allowed
Greater than 5:1 (50%)	Sparsely vegetated slope and it appears that sediment will travel with rain into watercourse	Not allowed

Table 1. Sidecasting guidelines. From: FishNet 4C (2004)

BERMS

- Do not leave loose soil piled in berms alongside the road or ditch. Loose or exposed soil berms are erodible and readily flushed into waterways and storm drains.
- If any berm is left in place for public safety reasons it must be compacted and stabilized with seeding or asphalt. Frequent well placed breaks in the berms are necessary to allow water to drain from road, preserving the natural drainage pattern of the slope.

Source Material for Road BMP RD-3.2 Grading

2004. FishNet 4C. Guidelines for Protecting Aquatic Habitat and Salmon Fisheries for County Road Maintenance.

2002. Five Counties Salmon Conservation Program. A Water Quality and Stream Habitat Protection Manual for County Road Maintenance.

RD-1.10 WATERBARS

DESCRIPTION

Waterbars are shallow, abrupt excavated dips or troughs with an adjacent, downslope hump or mounded berm, that are built at an oblique angle across the road (Figure 1 and 2). Waterbars are useful only on low standard seasonal or temporary, unsurfaced roads where winter use will not occur, because traffic easily cuts through the soft berm and fills the adjacent dip. Waterbars should be constructed at proper spacing according to the grade of the road (Table 3). Waterbars are usually regraded (smoothed out) at the beginning of each operating season, and then reconstructed at the beginning of each winter period.

Waterbars are high maintenance drainage structures that are prone to failure if not properly built and maintained. Unauthorized winter traffic is likely to break down waterbars and result in serious road surface erosion and water pollution.

BEST MANAGEMENT PRACTICES

- Waterbars and rolling dips should be spaced along the road close enough together that the road surface is not gullied (Table 3). Appropriate spacing of surface drainage structures depends on soil credibility and runoff rates. Look at local roads to determine the maximum spacing that will work in your specific area.

Erosion Hazard Rating (for surface erosion)	Road or Trail Gradient (%)			
	10% or less	11-25%	26-50%	over 50%
Extremely high	100'	75'	50'	50'
High	150'	100'	75'	50'
Moderate	200'	150'	100'	75'
Low	300'	200'	150'	100'

Table 3. From Weaver and Hagans (1994). ¹ Adapted from California Forest Practice Rules. This is the maximum distance between waterbars: when in doubt, reduce the spacing. Soils are nonrenewable and waterbars are inexpensive.




Figure 1. Waterbars are constructed on unsurfaced forest and ranch roads that will have little or no traffic during the wet winter period. The waterbar should be extended to the cutbank to intercept all ditch flow (1) and extend beyond the shoulder of the road. A berm (2) must block and prevent ditch flow from continuing down the road during flood flows. The excavated waterbar (3) should be skewed 30° to the ditch-line with the excavated material bermed on the downhill grade of the road (4). Water should always be discharged onto the downhill side on a stable slope protected by rip rap or vegetation (5). The cross ditch depth (6)

and width (7) must allow vehicle cross-over without destroying the function of the drain (B.C.M.F., 1991). From Weaver and Hagans (1994).




Figure 2. Typical design of a waterbar. From US Forest Service.

Source Material for Road BMP RD-7.8 Waterbars

1994. Weaver W.E. and D.K. Hagans. Handbook for Forest and Ranch Roads. Mendocino County Resource Conservation District

RD-1.11 DITCH RELIEF CULVERT **INSTALLATION**

DESCRIPTION

Ditch relief culverts (DRCs) divert water from an inside road ditch to an outside area beyond the outer edge of the road fill. DRCs take the flow through or beneath the road surface. Ditch relief culverts may also be used to filter water in a buffer zone prior to entering a waterway.

BEST MANAGEMENT PRACTICES

- Culverts should be designed and installed at intervals along the road that are close enough to prevent erosion of the ditch and at the culvert outfall, and at locations where collected water and sediment is not discharged directly into watercourses (Table 1).
- Install ditch relief culverts at an oblique (typically 30 degree) angle to the road so that ditch flow does not have to make a sharp angle turn to enter the pipe (Figure 1). On low gradient roads (<5%), where ditch flow is slow, ditch relief culverts can be installed at right angles to the road.
- Ditches should *neither* be discharged directly into the inlet of a watercourse crossing culvert, nor should ditch relief culverts discharge into a watercourse via surface flow without first directing flow through an adequate filter strip (Figure 2).
- In addition to installing ditch relief culverts on either approach to watercourse crossings, it is also advisable to consider installing ditch drains before curves, above and below through-cut road sections, and before and after steep sections of the road.
- If the ditch is on an insloped or crowned road that is very close to a stream, consider using outsloping to drain the road surface (see Road BMP RD-1.3, 1.4 Outslope Road). The ditch and the ditch relief culvert would then convey only spring flow from the cutbank, and not turbid runoff from the road surface.
- Do not discharge flow from ditch relief culverts onto unstable or highly erodible hillslopes
- Culverts should be installed at the gradient of the original ground slope, so it will emerge on the ground surface beyond the base of the fill. If not, either the fill below the culvert outlet should be armored with rock, or the culvert should be fitted with an anchored downspout to carry erosive flow past the base of the fill (Figure 1).
- Downspouts longer than 20 feet should be secured to the hillslope for stability. Full round downspouts are preferred over half-round downspouts.

Table 1. Maximum suggested spacing for ditch relief culverts¹ (ft)

Road grade (%)	Soil credibility				
	very high	high	moderate	slight	very low
2	600-800 ²				
4	530	600-800 ²			
6	355	585	600-800 ²		
8	265	425	525	600-800 ²	
10	160	340	420	555	
12	180	285	350	460	600-800 ²
14	155	245	300	365	560
16	135	215	270	345	490
18	118	190	240	310	435

¹Adapted from Transportation Handbook USDA Forest Service, R-6, 1966. Culvert spacing may be too great in locations where ditch runoff is accumulated and discharged onto steep hillslopes that are prone to gullying. Spacing is designed to control ditch erosion, not culvert outfall erosion, and are based on 25-year storm and precipitation rate of 1-2 in/hr for 15 minutes. If less, multiply by the intensity 0.50, 0.30, etc. If 2-3 in/hr, divide distance in table by 1.50; if 3-4 in/hr, divide by 1.75; and if 4-5 in/hr, divide by 2.00. The U.S. Forest Service also publishes abundant information on preventing and controlling gully erosion below culvert outfalls. From Hagans and Weaver (1994).

²Even with stable ditches, ditch relief culvert spacing greater than about 600 to 800 feet is generally not recommended due to the large volume of road surface and cutslope runoff that would be discharged through the culvert and onto lower slopes during peak runoff periods. Culvert outlet erosion may occur with less than 800 feet of contributing ditch line, so observe local conditions to determine the upper limit of acceptable spacing in your area.




Figure 1. Typical ditch relief culvert installation. (CDFG, 2006)




Figure 2. Where a road approaches a stream crossing (B), ditch flow should be culverted across the road (A,D) and discharged into a vegetated buffer that can filter the runoff before it reaches the watercourse. If the stream culvert plugs with debris or is topped by flood flows, flow will spillover the road at the change in grade at location "C" and back into the stream channel (modified from M.D.S.L. 1991). From Weaver and Hagans (1994).

Source Material for Road BMP 2.10 Ditch Relief Culvert Installation

2006. California Department of Fish and Game. Part X - Upslope Erosion Inventory and Sediment Control Guidance, California Salmonid Stream Habitat Restoration Manual.

2004. FishNet 4C. Guidelines for Protecting Aquatic Habitat and Salmon Fisheries for County Road Maintenance.

1994. Weaver W.E. and D.K. Hagans. Handbook for Forest and Ranch Roads. Mendocino County Resource Conservation District

RD-1.12 STREAM CROSSING INSTALLATION

DESCRIPTION

During road building, the construction of culverted stream crossings has the greatest potential of all activities to cause immediate sediment pollution. Culverts should be properly aligned, bedded, backfilled and covered, or they will be subject to eventual failure. In all cases, disturbance to the stream banks and streambed should be minimized during stream crossing construction.

BEST MANAGEMENT PRACTICES

- Culverts should be aligned with the natural stream channel. Correct alignment is critical for the culvert to function properly. Misalignment can result in bank erosion and debris plugging problems (Figure 69a).
- Stream crossing culverts should be placed at the base of the fill, and at the grade of the original streambed (Figure 1) (Figure 69d).
- Culvert should be inset slightly into the natural streambed so that water drops several inches as it enters the pipe. Culvert inlets set too low can plug with debris and those set too high can allow water to undercut the culvert (Figure 69b). Culverts placed midway up the outside of the fill are more likely to plug with sediment or organic debris, because their ability to pass materials is reduced, or to cause erosion of the fill below the culvert outlet (Figure 1).
- The culvert bed may be composed of either compacted rock-free soil, or gravel. If gravel is used for the bed, filter fabric will be needed to separate the gravel from the soil to minimize the potential for soil piping. Bedding beneath the culvert should provide for even distribution of the load over the length of the pipe.
- Inlet and outlet of the culvert should be armored. A metal, concrete, sandbag or rock head-wall can be constructed to prevent inlet erosion. A trash protector can be installed just upstream from the inlet where there is a hazard of floating limbs and wood chunks plugging the culvert inlet. This is especially important on logging roads where the upslope areas have recently been harvested or are slated for harvesting in the future.
- Stream crossings that are not at grade can be retrofitted with a downspout with rock placed at the outlet for armoring against hillslope erosion.




Figure 1. Typical stream crossing installation on non fish-bearing streams. From CDFG (2006).

Figure 69a, b. Proper culvert installation involves correct culvert orientation, setting the pipe slightly below the bed of the original stream, and backfilling and compacting the fill as it is placed over the culvert. Installing the inlet too low in the streambed (A) can lead to culvert plugging, yet if it is set too high (B) flow can undercut the inlet (from M.D.S.L., 1991).




Figure 69c. If the culvert outlet is placed too high in the fill (C), flow at the outlet will erode the fill.





Figure 69d. Placed correctly (D), the culvert is set slightly below the original stream, grade and protected with armor at the inlet and outlet.

Figures 69a,b,c,d. Typical stream crossing installation. From Hagans and Weaver (1994).

Source Material for Road BMP RD-2.8 Stream Crossing Installation

2006. California Department of Fish and Game. Part X - Upslope Erosion Inventory and Sediment Control Guidance, California Salmonid Stream Habitat Restoration Manual.

1994. Weaver W.E. and D.K. Hagans. Handbook for Forest and Ranch Roads. Mendocino County Resource Conservation District

RD-1.13 DRAINAGE FOR UNPAVED ROAD SURFACES

DESCRIPTION

Roads should be designed and constructed to cause minimal disruption of natural drainage patterns. Provisions for two components of road drainage should be included in every road project: 1) road surface drainage (including drainage which *originates* from the cutbank, road surface, and fillslope); and 2) hillslope drainage (including drainage from large springs, gullies, and streams which *cross* the road alignment).

BEST MANAGEMENT PRACTICES

- Maintain natural drainage patterns in watershed through installing drainage features to keep water within sub-basins.
- Crown or slope the road to avoid ponding or concentration of runoff. Outslope all roads where possible and safe (see Road BMP RD-1.3, 1.4 Outslope).
- Use rolling dips instead of ditch relief culverts (DRCs) when possible (Table 1) (Figure 1). Rolling dips require less maintenance and are less prone to failure than culverts (see Road BMP RD-1.8 Rolling Dips).
- Disconnect road drainage features from watershed hydrology. Shorten ditch lengths to stream crossings by installing a ditch relief culvert or rolling dip before the watercourse (see Road BMP RD-1.11 Ditch Relief Culvert Installation).
- In addition to installing DRCs on either approach to the stream crossings, it is also advisable to consider installing ditch drains before curves, above and below through-cut road sections, and before and after steep sections of the road.
- Ditches should neither be discharged directly into the inlet of a stream crossing culvert, nor should DRCs discharge into a watercourse without first directing flow through an adequate filter strip.
- Culverts should be designed and installed at intervals along the road that are close enough to prevent erosion of the ditch and at the culvert outfall. They should be installed at locations where collected water and sediment is not discharged directly into watercourses (Table 2).
- DRCs should not be used on erosive slopes without a downspout (see Construction BMP SS-11 Slope Drain).
- In areas of high erosion and/or storm runoff, *minimum* ditch relief culvert sizes should be 18 inches in diameter, and never less than 12 inches in other areas.
- A 10% grade to the culvert will usually be self cleaning. The culvert grade should also be at least 2% greater than the ditch which feeds it. The culvert should be placed at a 30 degree skew to the ditch to improve inlet efficiency and prevent plugging and erosion at the inlet.

- Stream crossings culverts and DRCs should be installed at the gradient of the original ground slope, so it will emerge on the ground surface beyond the base of the fill. If not, either the fill below the culvert outlet should be armored with rock, or the culvert should be fitted with an anchored downspout to carry erosive flow past the base of the fill (Figure 2) (see Road BMP RD1.12 Stream Crossing Installation).
- Culverts should be covered by a minimum of 1 foot of compacted soil, or a depth of 30% of its diameter, whichever is greater.
- Inlet protection, such as rock armoring or drop structures, can be used to help minimize erosion.
- DRCs must be spaced frequently enough to carry ditch and road surface waters without creating erosive concentrated flows. See attached table for spacing guidelines.

Road grade %	Upslope approach (distance from up-road start of rolling dip to trough) (ft)	Reverse grade (distance from trough to crest) (ft)	Depth below average road grade at discharge end of trough (ft)	Depth below average road grade at upslope end of trough (ft)
<6	55	15-20	0.9	0.3
8	65	15-20	1.0	0.2
10	75	15-20	1.1	.01
12	85	20-25	1.2	.01
>12	100	20-25	1.3	.01

Table 1. Table of rolling dips dimensions. From CDFG (2006).




Figure 1. Use of rolling dips to reduce ditch erosion and surface runoff. Rolling dips must drain the road surface and be driveable for the expected traffic. From CDFG (2006).




Figure 2. Typical ditch relief culvert installation. From CDFG (2002).

Table 2. Maximum suggested spacing for ditch relief culverts¹ (ft)

Road grade (%)	Soil credibility				
	very high	high	moderate	slight	very low
2	600-800 ²				
4	530	600-800 ²			
6	355	585	600-800 ²		
8	265	425	525	600-800 ²	
10	160	340	420	555	
12	180	285	350	460	600-800 ²
14	155	245	300	365	560
16	135	215	270	345	490
18	118	190	240	310	435

¹Adapted from Transportation Handbook USDA Forest Service, R-6, 1966. Culvert spacing may be too great in locations where ditch runoff is accumulated and discharged onto steep hillslopes that are prone to gullying. Spacing is designed to control ditch erosion, not culvert outfall erosion, and are based on 25-year storm and precipitation rate of 1-2 in/hr for 15 minutes. If less, multiply by the intensity 0.50, 0.30, etc. If 2-3 in/hr, divide distance in table by 1.50; if 3-4 in/hr, divide by 1.75; and if 4-5 in/hr, divide by 2.00. The U.S. Forest Service also publishes abundant information on preventing and controlling gully erosion below culvert outfalls. From Hagans and Weaver (1994).

²Even with stable ditches, ditch relief culvert spacing greater than about 600 to 800 feet is generally not recommended due to the large volume of road surface and cutslope runoff that would be discharged through the culvert and onto lower slopes during peak runoff periods. Culvert outlet erosion may occur with less than 800 feet of contributing ditch line, so observe local conditions to determine the upper limit of acceptable spacing in your area.

Source Material for Road BMP RD-1.3 Road Drainage for Unpaved Road Surface

2006. California Department of Fish and Game. Part X - Upslope Erosion Inventory and Sediment Control Guidance, California Salmonid Stream Habitat Restoration Manual.

1994. Weaver W.E. and D.K. Hagans. Handbook for Forest and Ranch Roads. Mendocino County Resource Conservation District

RD-1.14 ROAD SURFACE UPGRADE

DESCRIPTION

The road surface can be a big source of stream sediment. In some watersheds, it may be the primary source of accelerated (human-caused) erosion and sediment yield from the road system. Proper road construction and surfacing can significantly reduce this source of fine sediment. Permanent roads that are to be used for winter and wet weather hauling, including ranch roads and roads used for commercial hauling of forest products, need to be surfaced to improve trafficability and reduce erosion. Roads which receive heavy use should be inspected regularly to discover early signs of damage. Serious damage to road surfaces usually begins with the build up of thick (1-4 inch) accumulations of dry dust during the summer, or excess water (and mud) during the winter. Standing water is a sign of poor road drainage and ruts indicate that road strength is deteriorating.

BEST MANAGEMENT PRACTICES

- Follow Road BMPS in RD-1.4 Road Surfacing.
- A stable and well drained subgrade is essential for a good road. The load bearing capacity of a road depends upon the subgrade's soil strength, drainage and compaction characteristics (Table 23). Native material is often suitable, and can be used for the road's subgrade. Weak or wet subgrades (soils unable to support a load by themselves) need to be strengthened by adding loose or crushed rock or gravel to provide ballast and distribute the stress placed on the soil.
- Wet, low strength soils may be stabilized by the use of synthetic fabrics (geotextiles) designed specifically for this application. The fabric is spread over the subgrade and then covered with a layer of rock. Water passes through the membrane, but the wet soil remains below and does not mix with the surface aggregate. As a result, the road dries faster and the fabric spreads the wheel loading pressures over a large surface area.
- The running surface of the road should be smooth and hard-wearing, and it should not be subject to blowing or washing away. The most commonly used surfacing materials are angular (crushed) rock. In the past, river-run gravel was frequently used where crushed rock was not readily available. However, rounded material is not as well suited as long lasting surfacing material and may be difficult to keep in-place.
- First, a "base course" of 2 to 3 inch diameter angular rock is usually dumped on the compacted native road surface using dump trucks, spread to a uniform depth using a grader or tractor and then compacted. The use of true compaction equipment (instead of tractors) will provide the best, longest lasting road surface. Geotextile engineering fabrics can be used beneath the base course material if soil conditions are wet. A finer "surface course" several inches in thickness is then spread over the compacted base coarse material to provide a dense, smooth running surface. The resulting layers of angular, interlocking rock will provide a low impact road surface that can be used during much of the winter (Table 24) (Figure 1).
- For all-weather use, angular rock should be placed to a total depth of 6-10 inches, or more, which will then compact to a finished depth of 4 to 6 inches under normal use. Table 24 lists the volume of aggregate needed to surface one mile of road, ranging from 10-20 feet wide, to a depth of 1-6 inches.

Table 23. Soil characteristics for road subgrade materials¹

Material type	Strength, compaction and foundation suitability	Drainage	Reaction to frost	Common symbols of soil types ²
Clean gravels and clean sand ³	Good to excellent	Excellent	None to slight	GW, GP, SW, SP
Gravels and sands with non-plastic ⁴ fines	Good to excellent	Fair to poor	Slight to high	GMd, SMd
Gravels and sands with plastic ⁴ fines	Fair to good	Poor to impervious	Slight to high	GMu, GC, SMu, SC
Non-plastic and slightly plastic ⁴ silts and clays	Poor to fair	Fair to impervious (mostly poor)	Medium to high	ML, CL, OL
Medium and highly plastic ⁴ silts and clays	Very poor to poor	Poor to impervious (mostly poor)	Medium to very high	MH, CH
Peat and other highly organic soils	Very unstable, poor compaction	Fair to poor	Slight	Pt

¹ W.D.NJR. (1982)

² Unified Soil Classification System (USCS) symbol

³ "Clean" means less than about 12% of the material is smaller than 1/64" (the smallest particle visible to the naked eye)

⁴ Plasticity can be tested by simple field methods, including lightly wetting a hand sample, rolling the fines into a ball and then into a thread before it crumbles.

Non-plastic: a thread cannot be formed, regardless of the moisture content. Low plasticity: after 2-3 times, the molded ball will crumble.

Medium plasticity: After 3-5 times, the ball will easily crumble with moderate force (pressed between thumb and forefinger).

High plasticity: ball will not crumble, even with moderate force, after five times.

Table 23. From Weaver and Hagans (1994).

Figure 1. Cross section diagram showing typical base-course and surface-course application for forest and rand roads (USDA_SCS, 1983). From Weaver and Hagans (1994).




Table 24. Aggregate (yds³) required to one mile of road¹

Road width (ft)	Depth of uncompacted rock (inches)					
	2"	4"	6"	8"	10"	12"
10'	326	652	978	1,304	1,630	1,956
12'	391	782	1,174	1,564	1,956	2,348
14'	456	913	1,369	1,826	2,282	2,738
16'	522	1,043	1,565	2,086	2,608	3,130
18'	587	1,174	1,760	2,348	2,934	3,520
20'	652	1,304	1,956	2,608	3,260	3,912

¹ USDA (1978). Uncompacted, 16.3 yds³ equals 1 inch deep by 1 foot wide by 1 mile long. When aggregate is compacted, increase volumes required by 15-30%, depending on type and gradation of material.

From Weaver and Hagans (1994).

Source Material for Road BMP RD-6.2 Road Surface Upgrade

1994. Weaver W.E. and D.K. Hagans. Handbook for Forest and Ranch Roads. Mendocino County Resource Conservation District

RD-1.15 ROUTING AND LOCATION

DESCRIPTION

Roads should be plotted and located by a person with some knowledge of the area to be served by the road and of the terrain where the road is to be built. An engineer or geologist should be consulted in routing forest system roads to identify unstable terrain and to protect aquatic resources.

LIMITATIONS

Road system layout is influenced by many factors, including topography, property lines, obstacles (rock outcrops, unstable areas, etc), and proposed land use activities. Controls on the location of a road include both natural features and man-made elements (Table 1).

Control	Comment
Legal	Boundary lines limit the location of a road. Talk with adjacent landowners and work out written right-of-way agreements to share roads and reduce road construction.
Specific Location	The beginning and ending points of a road are often fixed. These represent major controls.
Safety	Each class of road and level of use have specific safety requirements. Common sense should be applied in setting speed, grades, curve radius, sight distance, and turnouts.
Pollution Control	Roads should avoid problem areas. Allow ample room to trap sediment in a buffer before it reaches a stream. Do not allow any direct discharge points where road runoff flows directly into the stream. Avoid flood plains, landslides, credible soils, etc., as well as slopes over 40% wherever possible.
Design Elements	Physical limits for curve radius, road grade, pitch grade, stopping distance and separation from streams are set by you. Design to reduce maintenance costs and pollution potential.
Migrating Fish	Observe and maintain substantial buffers. Know what species use your streams, their habitat requirements, the susceptible periods of their life cycle, and their environmental tolerance limits. Permits may be needed from the Department of Fish and Game.
Approach Roads Permits	Issued by California Department of Transportation of the County for roads connecting to public highways. Location for intersections may be restricted.

From Hagans and Weaver (1994). ¹ Adapted from USD A-SCS (1981).

BEST MANAGEMENT PRACTICES

- Identify and map the following conditions on the ground during the road layout process (Table 10):
 - favorable topography (especially benches and low gradient areas for landings turnouts and spoil disposal)
 - control points (the beginning and ending points, saddles and other sites)
 - obstacles (especially unstable or erodible soils, large rock outcrops and wet areas)
 - stream channels (including their degree of incision)
 - inner gorge locations
 - areas of steep slopes
 - any other obvious hazards or controls

Table 10. Some natural controls which affect road location ¹		
Control		Comment
Saddles		Major control for road location
Ridges		Major control and often a satisfactory road site.
Stream crossings		Major control. Seek locations with gentle side slopes and locations wide enough to accommodate the road. Good sites for bridges or culverts are needed. Evaluate for migratory fish where needed. Will need Fish and Game 1603 permit.
Benches		Often a good location for road junctions, switchbacks, landings, turnouts, etc.
Cliffs or rock outcrops		Cross above or below at a safe location. Rock which can be ripped is less costly to remove than hard rock needing blasting.
Slides		Major control. Avoid or cross at the safest point. Ask for professional geotechnical assistance.
Wetlands (bogs, swamps, wet meadows)		Major control. Avoid where possible or cross quickly at best point. May need Fish and Game clearance.
Valley floor	wide	Low gradient, desirable road location if above the flood line. If crossing, cross and get out of floodplain quickly. Little excavation required. Fish and Game permit may be required.
	narrow	Poor location because of flooding, erosion and pollution potential and high costs to cross the stream if it meanders. Keep road above floodplain. Fish and Game 1603 permit may be required.
Slopes	>40%, but <60%	Avoid sidecasting and sliver fills (thin blankets of fill placed on steep slopes) in which large bare areas are exposed to erosion. This loose sediment may be difficult to control because of long buffers needed.
	≥60%	Construction in unstable areas should be avoided. Full bench road construction and eroding material may be needed where slopes remain steep alongside stream channels. Proceed only with extreme caution. Avoid road construction on these steep slopes if possible.
	ridge crest	Good alignment and little excavation. Good drainage. Few culverts required. Adverse grade encountered on uneven ridges. Spur roads will have an adverse grade.
Aspect		Maintenance requirements in moist climates can be minimized by placing roads on south-facing slopes to promote drying and snow melt. In dry climates, (the north-facing slopes have more vegetation and may have less erosion. Extremely wet or dry climate negates this effect.
Rock slope (dip)		Place roads on the hillside where rocks dip (slant) into the hillside, not parallel to or out of the hillside. Consult a geologist for other problems and advice.
Soils		Where possible, avoid road building on naturally erodible soils. Check soils maps for potential problems and ask extension agents or the SCS for advice. Frozen soils require special care; ask for assistance.

From Weaver and Hagans (1994). ¹ Adapted from USDA-SCS (1981)

- Identify and evaluate nearby rock outcrops for potential rock aggregate for road surfacing materials.
- Identify broad ridge crests and benches as possible locations for landings, road turnouts and spoil disposal sites (Figure 1).
- Locate switchback with little or no grade so that trucks and equipment can pass safely and so they won't tear up the road surface while turning the corner and continuing up the road.




Figure 1.. Log landings on forest road systems should be kept to the absolute minimum size necessary to accommodate yarding, loading and hauling equipment and the minimum number needed to remove timber resources. Landings constructed on gentle ground and broad ridge crests far removed from stream channels are least likely to cause water quality problems, whereas landings built on steep slopes and near watercourses can result in severe impacts. From Weaver and Hagans (1994). Adapted from (USFS, 1963).

For more information, see Handbook for Forest and Ranch Roads. Weaver and Hagans (1994) and consult a trained engineer or geologist before construction. A trained wildlife biologist may be required to investigate for endangered species or species of special concern. An archaeologist may occasionally be needed to identify cultural sites that have to be avoided or mitigated before construction can begin.

Source Material for Road BMP RD-1.2 Routing and Location

1994. Weaver W.E. and D.K. Hagans. Handbook for Forest and Ranch Roads. Mendocino County Resource Conservation District

RD-1.16 UNDERSTANDING ROAD REMOVAL

DESCRIPTION

Approaches to removing roads may be divided into six categories: closure, abandonment, reclassification as trail, decommissioning, conversion to trail, and obliteration (Figure 1).

REMOVAL OPTIONS

Closure

Some agencies close roads with gates, berms, or deep ditches (tank traps) as an approach to road removal (see Road BMP RD-7.3 Road Closure). On-the-ground surveys indicate that conventional closure devices are ineffective at stopping road use by people intent on accessing restricted areas. With an effective device that prohibits motorized access, however, closure may reduce a road's terrestrial impacts by providing wildlife security. Even so, closure is an ineffective approach to removing a road, because the road continues to disrupt natural drainage patterns, cause soil erosion, and potentially initiate mass failures; in short, a closed road continues to impact aquatic ecosystems.

Abandonment

When a road is "abandoned," it is no longer maintained and may or may not be driveable based on physical conditions or the presence of vegetation. The Forest Service considers road abandonment a "no-action treatment" (Moll 1996). Like a closed road with an effective closure device, abandoned roads that no longer receive motorized use may reduce a road's terrestrial impacts by providing wildlife security. Simply discontinuing maintenance and abandoning a road, however, rarely prevents continuing and potential hydrologic problems. The presence of vegetation may provide the false idea that the road is recovering and is no longer problematic. Culverts can become plugged, and roads may continue to function as surface flow paths for water. Road fills may remain unstable and susceptible to failure. Because an abandoned road continues to impact aquatic ecosystems, abandonment is an ineffective approach to removing a road.

Reclassification as Trail

Reclassifying a road as a trail without restoring drainage patterns and stabilizing fill materials is not an effective approach to removing a road, especially if motorized use continues. Even if wildlife security is improved by stopping motorized use, simply reclassifying a road as a trail does not address a road's aquatic impacts; this type of approach is basically the same as abandonment. If a road is changed to a trail, it must be actively converted (see "Conversion to trail" below) by first stabilizing fill materials and dispersing concentrated water.

Decommissioning

Decommissioning is carried out to minimize shortterm sediment production, while "storing" a road for future use. Major treatments include removing stream crossings and stabilizing sidecast fill material. Site-specific drainage treatments such as constructing cross road drains, removing inboard ditches, and/or outsliping also help disperse concentrated water. Road surfaces may be mechanically scarified to facilitate revegetation. The goal of decommissioning is to leave much of the road prism intact so the road can be reconstructed in the future with only minimal effort. Decommissioning preserves most of the original construction investment, while reducing road-caused erosion and avoiding maintenance and/or repair costs. Other common terms used to indicate road removal with plans for future reconstruction

include storm-proofing, flood-proofing, erosion-proofing, putting-to-bed, deactivation, reclamation, hydrologic closure, hydrologic obliteration, and storage for future use. Planning for reconstruction and leaving much of the road prism intact may result in treating a road too lightly during removal. Future plans may change; post-decommissioning is too late to further treat the road for the long-term. Even if decommissioning stops road-related erosion in the shortterm, it is not the same as obliterating a road because the road is expected to be reconstructed. Even if roads may be reconstructed in the future, they should be removed as if reconstruction will not occur.

Conversion to Trail

Converting a road to a modest walking trail can be an effective approach to removing a road if all fill materials are stabilized before the trail is constructed. Some road-to-trail conversions are implemented by only partially recontouring a road, which may not stabilize all fill materials. Conversion is ineffective when ORVs are allowed because impacts associated with motorized use continue. Though trails are less intrusive and damaging than roads, they can cause similar impacts, such as stream sedimentation and facilitation of non-native species invasions.

Obliteration

Obliteration involves removing a road with no plans for future reconstruction. To be most effective, obliteration restores the original landform to the greatest extent possible. Stream crossings are removed and slopes are recontoured. Road surfaces and fill sites are ripped to improve subsurface water flow. Coarse woody debris placed on the recontoured road surface provides erosion protection, long-term nutrient sources, and wildlife habitat. Revegetation is also actively carried out with native species collected near the site. Fully obliterating roads speeds the restoration and recovery of hydrologic function, as well as ecological and evolutionary processes. If implemented appropriately, obliteration is the most effective approach to road removal since it addresses both terrestrial and aquatic impacts caused by roads.

Road impact considerations	How different approaches to removing roads address road impact considerations					
	Close	Abandon	Reclassify as trail	Decommission	Convert to trail	Obliterate
Is wildlife security improved?	Yes* (short-term)	Yes (long-term)	Depends on extent of trail use	Yes* (short-term)	Depends on extent of trail use	Yes* (long-term)
Are fill stability problems fixed?	No	No	No	Yes* (short-term)	Yes*	Yes*
Is surface erosion controlled?	No	No	No	Yes* (short-term)	No* (much reduced)	Yes*
Will the road be reopened or reconstructed?	Yes	No	No	Yes	No	No
Is motorized use accommodated? **	Yes	Yes (unless overgrown)	Yes	No*	Yes	No*
Will continued maintenance and repair funding be necessary?	Yes	No	Yes	No* (until reconstructed)	Yes	No*
* if implemented effectively ** decommissioned and obliterated roads may continue to accommodate winter use by snowmobiles						

Figure 1. From Bagley (1998).

REMOVAL TREATMENT OPTIONS

Specific road removal treatments include removing stream crossings, constructing cross road drains, ripping, recontouring, and outsloping. Each treatment is summarized below.

Stream Crossing

Stream crossing removal is a fundamental treatment for removing roads. When done correctly, stream crossings are removed by excavating all fill materials and restoring the original channel and valley shape. Simply removing culverts is not enough, because any remaining road fill will erode into the channel. Materials excavated from stream crossings can be used to recontour road segments to their natural slope, essentially returning fill to the location from which it was cut. Endhauling is necessary when the amount of fill removed is greater than that needed for recontouring. Any road removal project that does not remove stream crossings (or does not remove all fill materials) is not effective and may cause more ecological damage by causing additional sedimentation.

Cross Road Drains

Cross road drains are deep ditches excavated across road surfaces (similar to waterbars, but more substantial) to facilitate drainage on closed roads. They are too deep and steep to be cleared by motor vehicles. Unless spaced frequently enough to disperse concentrated water, cross road drains may cause erosion downslope. They must be constructed more frequently on roads with steep grades, but are not necessary if roads are fully recontoured or outsloped steeply.

Ripping

Ripping involves decompacting road surfaces and fill sites to a depth of two to three feet. The goal is to enhance subsurface water flow by reducing soil density and increasing porosity, infiltration, and percolation. Ripping relatively impermeable fill sites reduces the chance of fill saturation and failure. Some soil settling occurs since organic matter is limited in sterile road soils. Therefore, adding organic matter to the ripped soil can greatly accelerate the recovery of hydrologic function, including both infiltration and percolation (Luce 1997). Ripping also increases revegetation success.

Recontouring

Recontouring involves placing all fill materials back into locations where fill was removed during road construction. Recontouring restores the original slope as much as possible, dispersing concentrated water and greatly enhancing slope stability. Full recontouring is sometimes impossible, especially on very steep slopes, since the sidecast material may have slid downhill out of reach. In some cases, cutslopes will be so high and road cuts so narrow, that replaced fill material will not blend with the original undisturbed slope. Even so, slope recontouring to the extent possible generally results in the most stable landform shape, restores natural surface runoff patterns, and deters motorized access.

Outsloping

Outsloping involves filling inboard ditches with sidecast fill material and sloping the road surface to disperse water to the downhill side of the road. Some sidecast fill materials remain, but saturation and potential failure is reduced because water cannot concentrate in inboard ditches or on the road surface. The remaining fill slope materials may still cause stability problems, especially on steep slopes.

Source Material for Road BMP RD-7.2 Understanding Road Removal

1983. Bagley, Scott. The Road-Ripper's Guide to Wildland Road Removal. Wildlands Center for Preventing Roads

1994. Weaver W.E. and D.K. Hagans. Handbook for Forest and Ranch Roads. Mendocino County Resource Conservation District

RD-1.17 ROAD CLOSURE

DESCRIPTION

Road closure is an effective tool in managing road systems to protect private property, road systems, water quality, and sensitive landscapes. Choosing the access control treatment depends on the type of vehicle access to be discouraged and the length of the closure (Table 1). For example, closure treatments can be designed to discourage motorized traffic, but allow mountain biking or walking access. Closure treatments can also be designed to permanently close a road or allow seasonal treatments. The closure treatment chosen should reflect both the short term and long term use of the road system.

BEST MANAGEMENT PRACTICES


Closure Type	Description	Purpose Application
Blockage with On-Site Materials	Rock, logs, stumps, slash piles, posts, water bars, tank traps, decomposition	Discourage use, economical, dependent on-site and available material
Vegetative Planting, Seeding	Trees, shrubs, cactus, and grass seeding, recycled paper mulch, chip and spread slash	Discourage use, camouflage road, speed revegetation and healing of site, provide browse and forage
Imported Material	Fences, gates, posts, guardrails, concrete barriers	Discourage use, lack of on-site material or inappropriate site for use of on-site materials
Pole Fences Wood Barriers	Onsite or imported poles, reinforce with metal strips to deter chain-sawing	Discourage use, can be dismantled for emergency access, aesthetically pleasing
Closure Devices	Materials used include metal telescoping tubing, pipe, and well casing. Available in single lane to double lane widths	Discourage use, allow quick easy access, single or multiple locks, signing
Obliteration	Re-contour road junction or entire road. Combine with other closure treatments. Removal of drainage structures, bridges, and associated embankments	Eliminate travelway, return corridor to resource production, reduce modifications to hydrology and aesthetics, camouflage road

Table 1. Access Control Treatments. Adapted from US Forest Service 1996.

Source Material for Road BMP RD-7.3 Road Closure

1996. US Forest Service. A Guide for Road Closure and Obliteration in the Forest Service. Technology and Development Program. Publication: 9677 1205.

EC-1.1 JUTE MAT BLANKET



- JUTE MAT BLANKET**
1. SLOPE SURFACE SHALL BE FREE OF ROCK, CLODS, STICKS AND GRASS MATS. BLANKETS SHALL HAVE GOOD SOIL CONTACT.
 2. APPLY PERMANENT SEEDING BEFORE PLACING BLANKETS.
 3. LAY BLANKETS LOOSELY AND STAKE OR STAPLE TO MAINTAIN DIRECT CONTACT WITH THE SOIL. DO NOT STRETCH.
 4. MATS/BLANKETS SHOULD BE INSTALLED VERTICALLY DOWNSLOPE AND OVERLAPPED IN THE DIRECTION OF FLOW.

EC-1.2 CULVERT OUTLET ENERGY DISSIPATER

DESCRIPTION

An energy dissipater is a structure designed to control erosion at the outlet of a culvert or conduit by reducing the velocity of flow and dissipating the energy (see BMP SS-10 Outlet Protection/ Velocity Dissipation Devices).

LIMITATIONS

- Do not use this BMP below the mean high water line of any water body before obtaining appropriate permits. Due to issues relative to Corps 404 jurisdiction sometimes energy dissipaters are not placed below the ordinary high water mark which results in increased erosion.
- Consider other energy dissipaters such as concrete impact basins, paved outlet structures, or a half culvert where site conditions warrant.
- Rock/riprap dissipaters may require containment in mattresses to maintain their effectiveness.

BEST MANAGEMENT PRACTICES

- Size rock to handle high velocity storm events.
- Key rock into sides of fillslope to prevent undercutting (Figure 1).
- Best results are obtained when sound, durable, angular rock is used (Figure 2).
- Inspect after each significant rain for erosion and/or disruption of the rock, and repair immediately.




Figure 1. Flared outlet with rock energy dissipater. From Weber County, UT.




Figure 2. Rock energy dissipator. From 2004 Fishnet 4C. Adapted from 1994 McCullah.

Source Material for Road BMP RD-2.12 Culvert Outlet Energy Dissipator

2004. FishNet 4C. Guidelines for Protecting Aquatic Habitat and Salmon Fisheries for County Road Maintenance.

N/A. Weber County, Engineering Department. Ogden, Utah.

EC-1.3 OUTLET PROTECTION

DESCRIPTION

A rock outlet protection is a physical device composed of rock, riprap, grouted riprap, or concrete rubble which is placed at the outlet of a pipe to prevent scour of the soil caused by high pipe flow velocities, and to absorb flow energy to produce nonerosive velocities (see Construction BMP SS-10 Outlet Protection/ Velocity Dissipation Devices).

APPLICATIONS:

- Wherever discharge velocities and energies at the outlets of culverts, conduits, or channels are sufficient to erode the next downstream reach.
- Rock outlet protection is best suited for temporary use during construction because it is usually less expensive and easier to install than concrete aprons or an energy dissipater (Figure 1) (see Erosion Control BMP EC-1.3 Energy Dissipater).
- A sediment trap below the pipe outlet is recommended if runoff is sediment laden (Figure 2).
- Permanent rock riprap protection should be designed and sized by the engineer as part of the culvert, conduit or channel design (Figure 2).
- Grouted riprap should be avoided in areas of freeze and thaw because the grout will break up.

LIMITATIONS

- Large storms often wash away the rock outlet protection and leave the area susceptible to erosion.
- Sediment captured by the rock outlet protection may be difficult to remove without removing the rock.
- Outlet protection may negatively impact the channel habitat in streams.

BEST MANAGEMENT PRACTICES

- Size rock to handle high velocity storm events (Figure 3).
- Key rock into sides of fillslope to prevent undercutting.
- Best results are obtained when sound, durable, angular rock is used.
- Inspect after each significant rain for erosion and/or disruption of the rock, and repair immediately.




Figure 1. Flared outlet with energy dissipater. From Caltrans (2003). (Adapted from USDA-SCS).




Figure 2. Rock energy dissipater. From 2004 Fishnet 4C. Adapted from 1994 McCullah.




Figure 3. Rock armoring on shotgun culvert outlet. Photo Courtesy of California Department of Transportation (Caltrans).

Source Material for Road BMP RD-2.11 Outlet Protection

2003. California Department of Transportation (CALTRANS). Storm Water Quality Handbooks – Construction Site Best Management Practices (BMPs) Manual.

2004. FishNet 4C. Guidelines for Protecting Aquatic Habitat and Salmon Fisheries for County Road Maintenance.

EC-1.4 STOCKPILE MANAGEMENT

DESCRIPTION

This activity involves the selection of sites in advance of the need for long-term and short-term stockpiling of materials for road maintenance activities and disposing of excess materials from excavations, grading and culvert basin cleaning. The general watershed criteria for selecting any disposal site is a site where the material will not erode into any part of the channel network, and where it will not initiate a formerly dormant landslide.

ENVIRONMENTAL CONCERNS

- Filling wetlands with spoil material.
- Discharge of sediment, debris, or organic material into the stream or storm water discharge system.
- Destruction or harm to aquatic, riparian or wetland habitat, or to endangered or threatened plant and animal species due to placement of fill material.
- Surface or groundwater impacts from leachate formed in organic material disposal sites.
- Damage to endangered or threatened plant species on site.
- Slope stability of both the disposal site and the spoil pile.

BEST MANAGEMENT PRACTICES

Site Selection

- Determine the location of existing disposal sites, potential disposal sites, and locations of significant spoil generation along roads.
 - Conduct site investigations of existing and potentially suitable disposal sites. Site investigations should include the disposal area size, distance to watercourses, potential slope instabilities, listed species habitat, archaeological sites, nearby residential areas, access, and other limiting factors.
 - Prepare a map and data set indicating sites (existing and potential) with acceptable site characteristics (see below). Prioritize acceptable sites.
 - Develop site plans for sites adjacent to or near riparian areas or streams to identify erosion and sediment control needs, and to ensure stability of the material.
- Follow these acceptable site characteristics in the site election & design process:
 - Seek a stable site where sediment cannot reach the stream during any high water event.
 - Avoid adjacent riparian corridors or any area within the 100-year floodplain.
 - Avoid all wetland sites as these sites are protected from disposal activities and permits will be required and may not be granted.
 - Avoid placing spoil on unstable slopes, where the added weight could trigger a land movement. Excessive loading of clay or silt soils could also trigger a failure.
 - Use wide, stable locations such as rock pits, ridges, and benches as places to dispose of fill. Avoid locations where ground water emerges or a thick organic layer is present. Do not leave loose soil piled in berms alongside the road or ditch.

- Avoid sites with endangered or threatened plant species. Search the California Natural Diversity Database (www.dfg.ca.gov/whdab/html/cnddb.html) for any known listed plant sites in the area. Seek site evaluations by qualified botanists during the appropriate season before selecting a new site.

Implementation

- Locate stockpiles a minimum of 50 ft away from concentrated flows of stormwater, drainage courses, and inlets.
- Protect all stockpiles from stormwater run-on using a temporary perimeter sediment barrier such as berms, dikes, fiber rolls, silt fences, gravel bags, or straw bale barriers.
- During the rainy season, soil stockpiles should be covered or protected with soil stabilization measures and a temporary perimeter sediment barrier at all times.
- During the non-rainy season, soil stockpiles should be covered or protected with a temporary perimeter sediment barrier prior to the onset of precipitation (Figure 1).
- Apply erosion and sediment control BMPs as needed.
- Place bagged materials on pallets and under cover.
- Implement wind erosion control practices as appropriate on all stockpiled material. For specific information.
- The performance of erosion control BMPs should be monitored routinely during construction, especially during and after storm events. BMPs should be maintained or upgraded as needed.
- Manage stockpiles of contaminated soil in accordance with State and Federal Regulations.
- Avoid sidecasting of soil in all cases where it could be delivered into a watercourse, riparian area, roadside ditch or storm drain. Do not sidecast outside of the landowner right-of-way without landowner's permission. In some instances, under the following guidelines (See Table 1), sidecasting is allowable given remote distances from spoils storage sites. In these cases, the setback distance required depends on slope and vegetation. The presence of vegetation helps to slow the travel of sediment downslope, so good judgment is needed to assess the situation. *Do not sidecast at all* if the slope is sparsely vegetated and it appears that sediment will travel with rain runoff into a stream or estuary system, even if setback distances are applied. On slopes of 5:1 (20% gradient) or less, sidecasting is allowed beyond 150 feet of a watercourse, stream crossing, riparian area, roadside ditch or storm drain. On 2:1 slopes (50%) or less, sidecasting is allowed beyond 300 feet of a watercourse, stream crossing, riparian area, roadside ditch or storm drain. On slopes greater than 2:1, typically sidecasting is *not recommended*, however there may be rare instances on slopes greater than 2:1 where sidecasting is acceptable given very long distances from waterbodies and good vegetative cover. Seek advice from local fisheries agency staff when in doubt. Avoid concentrating sidecasting repeatedly in the same place. Never sidecast large amounts of soil from major landslides.

SLOPE GRADIENT	DISTANCE FROM WATERCOURSE, STREAM CROSSING, RIPARIAN AREA, ROADSIDE DITCH, STORM DRAIN	SIDECASTING RULE
Any slope	Appears that sediment will travel with rainwater into watercourse.	Not allowed
5:1 (20%) or less	150 feet or more	Allowed using good judgment
2:1 (50%) or less	300 feet or more	Allowed using good judgment
Greater than 2:1 (50%)	Vegetated slope long distance from watercourse	Allowed
Greater than 2:1 (50%)	Sparse vegetated slope and it appears that sediment will travel with rain into watercourse	Not allowed

Table 1. Sidecasting BMP. From FishNet 4C (2004).



Figure 1. Stock piles should be covered with erosion and sediment control BMPs employed to keep sediment on site. From Caltrans (2003).



Source Material for Road BMP RD-2.16 Stockpile Management

2003. California Department of Transportation (CALTRANS). Storm Water Quality Handbooks – Construction Site Best Management Practices (BMPs) Manual.

2004. FishNet 4C. Guidelines for Protecting Aquatic Habitat and Salmon Fisheries for County Road Maintenance.

Straw Mulch

SS-6



Standard Symbol

- BMP Objectives**
- Soil Stabilization
 - Sediment Control
 - Tracking Control
 - Wind Erosion Control
 - Non-Storm Water Management
 - Materials and Waste Management

Definition and Purpose Straw mulch consists of placing a uniform layer of straw and incorporating it into the soil with a studded roller or anchoring it with a stabilizing emulsion. This is one of five temporary soil stabilization alternatives to consider.

- Appropriate Applications**
- Straw mulch is typically used for soil stabilization as a temporary surface cover on disturbed areas until soils can be prepared for revegetation and permanent vegetation is established.
 - Also typically used in combination with temporary and/or permanent seeding strategies to enhance plant establishment.

- Limitations**
- Availability of erosion control contractors and straw may be limited prior to the rainy season due to high demand.
 - There is a potential for introduction of weed-seed and unwanted plant material.
 - When straw blowers are used to apply straw mulch, the treatment areas must be within 45 m (150 ft) of a road or surface capable of supporting trucks.
 - Straw mulch applied by hand is more time intensive and potentially costly.
 - May have to be removed prior to permanent seeding or soil stabilization.
 - “Punching” of straw does not work in sandy soils.

Straw Mulch

SS-6

- Standards and Specifications
- Straw shall be derived from wheat, rice, or barley.
 - All materials shall conform to Standard Specifications Sections 20-2.06, 20-2.07 and 20-2.11.
 - A tackifier is the preferred method for anchoring straw mulch to the soil on slopes.
 - Crimping, punch roller-type rollers, or track-walking may also be used to incorporate straw mulch into the soil on slopes. Track walking shall only be used where other methods are impractical.
 - Avoid placing straw onto the traveled way, sidewalks, lined drainage channels, sound walls, and existing vegetation.
 - Straw mulch with tackifier shall not be applied during or immediately before rainfall.

Application Procedures

- Apply loose straw at a minimum rate of 3,570 kg/ha (4,000 lb/ac), or as indicated in the project's special provisions, either by machine or by hand distribution.
- If stabilizing emulsion will be used to anchor the straw mulch in lieu of incorporation, roughen embankment or fill areas by rolling with a crimping or punching-type roller or by track walking before placing the straw mulch. Track walking should only be used where rolling is impractical.
- The straw mulch must be evenly distributed on the soil surface.
- Anchor the mulch in place by using a tackifier or by "punching" it into the soil mechanically (incorporating).
- A tackifier acts to glue the straw fibers together and to the soil surface. The tackifier shall be selected based on longevity and ability to hold the fibers in place.
- A tackifier is typically applied at a rate of 140 kg/ha (125 lb/ac). In windy conditions, the rates are typically 200 kg/ha (178 lb/ac).
- Methods for holding the straw mulch in place depend upon the slope steepness, accessibility, soil conditions and longevity. If the selected method is incorporation of straw mulch into the soil, then do as follows:
 - Applying and incorporating straw shall follow the requirements in Standard Specifications Section 20-3.03.
 - On small areas, a spade or shovel can be used.

Straw Mulch

SS-6



- On slopes with soils, which are stable enough and of sufficient gradient to safely support construction equipment without contributing to compaction and instability problems, straw can be “punched” into the ground using a knife-blade roller or a straight bladed coultter, known commercially as a “crimper.”
 - On small areas and/or steep slopes, straw can also be held in place using plastic netting or jute. The netting shall be held in place using 11 gauge wire staples, geotextile pins or wooden stakes. Refer to BMP SS-7, “Geotextiles, Plastic Covers and Erosion Control Blankets/Mats.”
- Maintenance and Inspections
- The key consideration in Maintenance and Inspection is that the straw needs to last long enough to achieve erosion control objectives.
 - Maintain an unbroken, temporary mulched ground cover while DSAs are non-active. Repair any damaged ground cover and re-mulch exposed areas.
 - Reapplication of straw mulch and tackifier may be required by the Resident Engineer (RE) to maintain effective soil stabilization over disturbed areas and slopes.
 - After any rainfall event, the Contractor is responsible for maintaining all slopes to prevent erosion.

Source Material for Construction BMP SS-6

2003. State of California Department of Transportation. Caltrans Storm Water Quality Handbook Construction Site BMP Manual.

Geotextiles, Mats, Plastic Covers and Erosion Control Blankets

SS-7



Standard Symbol

BMP Objectives

- Soil Stabilization
- Sediment Control
- Tracking Control
- Wind Erosion Control
- Non-Storm Water Management
- Materials and Waste Management

Definition and Purpose This Best Management Practice (BMP) involves the placement of geotextiles, mats, plastic covers, or erosion control blankets to stabilize disturbed soil areas and protect soils from erosion by wind or water. This is one of five temporary soil stabilization alternatives to consider.

Appropriate Applications These measures are used when disturbed soils may be particularly difficult to stabilize, including the following situations:

- Steep slopes, generally steeper than 1:3 (V:H).
- Slopes where the erosion potential is high.
- Slopes and disturbed soils where mulch must be anchored.
- Disturbed areas where plants are slow to develop.
- Channels with flows exceeding 1.0 m/s (3.3 ft/s).
- Channels to be vegetated.
- Stockpiles.
- Slopes adjacent to water bodies of Environmentally Sensitive Areas (ESAs).

Geotextiles, Mats, Plastic Covers and Erosion Control Blankets

SS-7

- Limitations**
- Blankets and mats are more expensive than other erosion control measures, due to labor and material costs. This usually limits their application to areas inaccessible to hydraulic equipment, or where other measures are not applicable, such as channels.
 - Blankets and mats are generally not suitable for excessively rocky sites, or areas where the final vegetation will be mowed (since staples and netting can catch in mowers).
 - Blankets and mats must be removed and disposed of prior to application of permanent soil stabilization measures.
 - Plastic sheeting is easily vandalized, easily torn, photodegradable, and must be disposed of at a landfill.
 - Plastic results in 100% runoff, which may cause serious erosion problems in the areas receiving the increased flow.
 - The use of plastic shall be limited to covering stockpiles, or very small graded areas for short periods of time (such as through one imminent storm event), until alternative measures, such as seeding and mulching, may be installed.
 - Geotextiles, mats, plastic covers, and erosion control covers have maximum flow rate limitations; consult the manufacturer for proper selection.

**Standards and
Specifications**

Material Selection

There are many types of erosion control blankets and mats, and selection of the appropriate type shall be based on the specific type of application and site conditions. Selection(s) made by the Contractor must be approved by the Resident Engineer (RE); certification of compliance shall be in accordance with Standard Specifications Section 6-1.07.

Site Preparation

- Proper site preparation is essential to ensure complete contact of the blanket or matting with the soil.
- Grade and shape the area of installation.
- Remove all rocks, clods, vegetation or other obstructions so that the installed blankets or mats will have complete, direct contact with the soil.
- Prepare seedbed by loosening 50 mm (2 in) to 75 mm (3 in) of topsoil.

Seeding

Seed the area before blanket installation for erosion control and revegetation. Seeding after mat installation is often specified for turf reinforcement application. When seeding prior to blanket installation, all check slots and other areas disturbed during installation must be re-seeded. Where soil filling is specified, seed the matting and the entire disturbed area after installation and prior to filling the mat with soil.

Geotextiles, Mats, Plastic Covers and Erosion Control Blankets

SS-7

Maintenance and Inspection Areas treated with temporary soil stabilization shall be inspected as specified in the special provisions. Areas treated with temporary soil stabilization shall be maintained to provide adequate erosion control. Temporary soil stabilization shall be reapplied or replaced on exposed soils when area becomes exposed or exhibits visible erosion.



- All blankets and mats shall be inspected periodically after installation.
- Installation shall be inspected after significant rain storms to check for erosion and undermining. Any failures shall be repaired immediately.
- If washout or breakage occurs, re-install the material after repairing the damage to the slope or channel.

**Source Material for Construction BMP SS-7 Geotextiles, Mats, Plastic Covers
and Erosion Control Blankets**

2003. State of California Department of Transportation. Caltrans Storm Water Quality Handbook Construction Site BMP Manual.

Outlet Protection/Velocity Dissipation Devices

SS-10



Standard Symbol

BMP Objectives

- Soil Stabilization
- Sediment Control
- Tracking Control
- Wind Erosion Control
- Non-Storm Water Management
- Materials and Waste Management

Definition and Purpose These devices are placed at pipe outlets to prevent scour and reduce the velocity and/or energy of storm water flows.

- Appropriate Applications**
- These devices may be used at the following locations:
 - Outlets of pipes, drains, culverts, slope drains, diversion ditches, swales, conduits or channels.
 - Outlets located at the bottom of mild to steep slopes.
 - Discharge outlets that carry continuous flows of water.
 - Outlets subject to short, intense flows of water, such as flash floods.
 - Points where lined conveyances discharge to unlined conveyances.
 - This BMP may be implemented on a project-by-project basis with other BMPs when determined necessary and feasible by the Resident Engineer (RE).

- Limitations**
- Loose rock may have stones washed away during high flows.
 - Grouted riprap may break up in areas of freeze and thaw.
 - If there is not adequate drainage, and water builds up behind grouted riprap, it may cause the grouted riprap to break up due to the resulting hydrostatic pressure.



Outlet Protection/Velocity Dissipation Devices

SS-10

- Standards and Specifications**
- There are many types of energy dissipaters, with rock being the one that is represented in the figure on Page 3. Please note that this is only one example and the RE may approve other types of devices proposed by the contractor.
 - Install riprap, grouted riprap, or concrete apron at selected outlet. Riprap aprons are best suited for temporary use during construction.
 - Carefully place riprap to avoid damaging the filter fabric.
 - For proper operation of apron:
 - Align apron with receiving stream and keep straight throughout its length. If a curve is needed to fit site conditions, place it in upper section of apron.
 - If size of apron riprap is large, protect underlying filter fabric with a gravel blanket.
 - Outlets on slopes steeper than 10% shall have additional protection.
- Maintenance and Inspection**
- Inspect temporary measures prior to the rainy season, after rainfall events, and regularly (approximately once per week) during the rainy season.
 - Inspect apron for displacement of the riprap and/or damage to the underlying fabric. Repair fabric and replace riprap that has washed away.
 - Inspect for scour beneath the riprap and around the outlet. Repair damage to slopes or underlying filter fabric immediately.
 - Temporary devices shall be completely removed as soon as the surrounding drainage area has been stabilized, or at the completion of construction.

Outlet Protection/Velocity Dissipation Devices

SS-10



Pipe Diameter mm	Discharge m^3/s	Apron Length, L_a m	Rip Rap D_{50} Diameter Min mm
300	0.14	3	100
	0.28	4	150
450	0.28	3	150
	0.57	5	200
	0.85	7	300
	1.13	8	400
600	0.85	5	200
	1.13	8	200
	1.42	8	300
	1.70	9	400

For larger or higher flows, consult a Registered Civil Engineer



Source: USDA – SCS

Source Material for Construction BMP SS-10 Outlet Protection

2003. State of California Department of Transportation. Caltrans Storm Water Quality Handbook Construction Site BMP Manual.

Slope Drains

SS-11



Standard Symbol

- BMP Objectives**
- Soil Stabilization
 - Sediment Control
 - Tracking Control
 - Wind Erosion Control
 - Non-Storm Water Management
 - Materials and Waste Management

Definition and Purpose A slope drain is a pipe used to intercept and direct surface runoff or groundwater into a stabilized watercourse, trapping device or stabilized area. Slope drains are used with lined ditches to intercept and direct surface flow away from slope areas to protect cut or fill slopes.

- Appropriate Applications**
- Slope drains may be used on construction sites where slopes may be eroded by surface runoff.
 - This BMP may be implemented on a project-by-project basis with other BMPs when determined necessary and feasible by the Resident Engineer (RE).

- Limitations**
- Severe erosion may result when slope drains fail by overtopping, piping, or pipe separation.

- Standards and Specifications**
- When using slope drains, limit drainage area to 4 ha (10 ac) per pipe. For larger areas, use a rock-lined channel or a series of pipes.
 - Maximum slope generally limited to 1:2 (V:H), as energy dissipation below steeper slopes is difficult.
 - Direct surface runoff to slope drains with interceptor dikes. See BMP SS-8, “Earth Dikes/Drainage Swales, and Lined Ditches.”
 - Slope drains can be placed on or buried underneath the slope surface.
 - Recommended materials are PVC, ABS, or comparable pipe.
 - When installing slope drains:
 - Install slope drains perpendicular to slope contours.

Slope Drains

SS-11


- Compact soil around and under entrance, outlet, and along length of pipe.
- Securely anchor and stabilize pipe and appurtenances into soil.
- Check to ensure that pipe connections are water tight.
- Protect area around inlet with filter cloth. Protect outlet with riprap or other energy dissipation device. For high energy discharges, reinforce riprap with concrete or use reinforced concrete device.
- Protect inlet and outlet of slope drains; use standard flared end section at entrance and exit for pipe slope drains 300 mm (12in) and larger.

Maintenance and Inspection

- Inspect before and after each rain storm, and twice monthly until the tributary drainage area has been stabilized. Follow routine inspection procedures for inlets thereafter.
- Inspect outlet for erosion and downstream scour. If eroded, repair damage and install additional energy dissipation measures. If downstream scour is occurring, it may be necessary to reduce flows being discharged into the channel unless other preventative measures are implemented.
- Inspect slope drainage for accumulations of debris and sediment.
- Remove built-up sediment from entrances, outlets, and within drains as required.
- Make sure water is not ponding onto inappropriate areas (e.g., active traffic lanes, material storage areas, etc.).

Slope Drains

SS-11




TYPICAL SLOPE DRAIN
NOT TO SCALE

Source Material for Construction BMP SS-11 Slope Drains


2003. State of California Department of Transportation. Caltrans Storm Water Quality Handbook Construction Site BMP Manual.

SC-1.1 CHECK DAMS




CHECK DAMS:


1. CHECK DAMS SHALL BE INSTALLED AT ALL LOCATIONS INDICATED ON THE WRPP, AND AT ANY OTHER LOCATION DEEMED NECESSARY BY THE SITE CONTRACTOR.
2. CHECK DAMS SHOULD BE SPACED SO THAT THE TOE OF CHECK DAM IS THE SAME ELEVATION AS THE TOP OF THE CHECK DAM BELOW.
3. CHECK DAMS SHOULD BE IMBEDDED IN CHANNEL A MINIMUM OF 4"-6"
4. CHECK DAMS THAT EXCEED A HEIGHT OF 3' SHOULD BE DESIGNED BY A QUALIFIED ENGINEER, GEOLOGIST, OR EROSION CONTROL SPECIALIST.
5. CHECK DAMS SHALL BE INSPECTED PERIODICALLY THROUGHOUT THE COURSE OF CONSTRUCTION, ONCE AFTER EACH RAINFALL EVENT, AND ONCE EVERY 24 HOURS DURING EXTENDED RAINFALL EVENTS. ANY SPLIT, TORN, UNRAVELED OR SLUMPING FIBER ROLLS SHALL BE REPAIRED OR REPLACED IMMEDIATELY.




SC1.2 TEMPORARY SEDIMENT BASIN




SC-1.3 FIBER ROLLS



PLAN VIEW



ENLARGED VIEW



NOTE: SLASH WILL BE REMOVED FROM THE PERIMETER AND WILL BE HAND PLACED THROUGHOUT THE LEVEL AREAS IN ORDER TO BREAK-UP OR SLOW THE RUNOFF VELOCITIES

NOTE: PORTIONS ARE EXAGGERATED FOR CLARITY

ELEVATION VIEW

FIBER ROLLS:

1. FIBER ROLLS SHALL BE INSTALLED AT ALL LOCATIONS INDICATED ON THE WRPP, AND AT ANY OTHER LOCATION DEEMED NECESSARY BY THE SITE CONTRACTOR.
2. FIBER ROLLS SHOULD BE USED ALONG THE FACE OF EXPOSED SLOPES TO SHORTEN SLOPE LENGTH AND DECREASE FLOW VELOCITY; AT GRADE BREAKS WHERE SLOPES TRANSITION TO STEEPER SLOPES; AND ALONG STREAM BANKS TO ASSIST STABILIZATION, AND IN DRAINAGE SWALES TO SLOW FLOWS. ON 1:1 SLOPES PLACE FIBER ROLLS SPACED AT 10' INTERVALS PARALLEL TO SLOPE, ON 1.5:1 SLOPES PLACE FIBER ROLLS SPACED AT 15' INTERVALS PARALLEL TO SLOPE, AND ON 2:1 SLOPES PLACE FIBER ROLLS SPACED AT 20' INTERVALS PARALLEL TO SLOPE.
3. FIBER ROLLS SHALL CONSIST OF BIODEGRADABLE FIBERS STUFFED INTO A PHOTO-DEGRADABLE OPEN WEAVE NETTING. THEY SHALL BE DESIGNED TO ALLOW WATER TO PASS THROUGH THE FIBERS; TO TRAP SUSPENDED SEDIMENT; INCREASE FILTRATION RATES; AND TO SLOW RUNOFF.
4. FIBER ROLLS SHALL BE PLACED SUCH THAT THEY OVERLAP AND FOLLOW THE CONTOUR LINES OF THE SLOPE ON WHICH THEY ARE PLACED.
5. FIBER ROLLS SHALL BE INSPECTED PERIODICALLY THROUGHOUT THE COURSE OF CONSTRUCTION, ONCE AFTER EACH RAINFALL EVENT, AND ONCE EVERY 24 HOURS DURING EXTENDED RAINFALL EVENTS. ANY SPLIT, TORN, UNRAVELED OR SLUMPING FIBER ROLLS SHALL BE REPAIRED OR REPLACED IMMEDIATELY.

ROAD BMP RESOURCES

DESCRIPTION

Listed below are some of the resource materials for Road BMPs that are available for landowners.

2006. California Department of Fish and Game. Part X - Upslope Erosion Inventory and Sediment Control Guidance, California Salmonid Stream Habitat Restoration Manual.

Available at:

California Department of Fish and Game
Inland Fisheries Division
ATTN: Salmonid Habitat Restoration Coordinator
1416 Ninth Street, Sacramento, CA 95814 (916) 654-5997
or
www.dfg.ca.gov/fish/resources/habitatmanual.asp

2003. California Department of Transportation (CALTRANS). Storm Water Quality Handbooks – Construction Site Best Management Practices (BMPs) Manual.

Available at:

www.dot.ca.gov/hq/construc/stormwater/CSBMPPM_303_Final.pdf

2009. California Stormwater Quality Association (CASQA). California Stormwater BMP Handbook.

Available at:

California Stormwater Quality Association
PO Box 2105
Menlo Park, CA 94026
or
www.cabmphandbooks.com

2004. FishNet 4C. Guidelines for Protecting Aquatic Habitat and Salmon Fisheries for County Road Maintenance.

Available at:

3820 Cypress Dr., Suite 11
Petaluma, CA 94954 Phone: 707.762.1336
or
http://fishnet.marin.org/projects_roads_manual.html

2002. Five Counties Salmon Conservation Program. A Water Quality and Stream Habitat Protection Manual for County Road Maintenance.

Available at:

www.5counties.org/Projects/FinalGeneralProjectPages/RoadsManual800.htm

1996. US Forest Service. A Guide for Road Closure and Obliteration In the Forest Service. Technology and Development Program. Publication: 9677 1205.

Available at:

www.fs.fed.us/eng/pubs/pdfimage/96771205.pdf

2014. Weaver W.E., Wepner E. and Hagans D.K. Handbook for Forest, Ranch, and Rural Roads. Mendocino County Resource Conservation District.

Available at:

Mendocino County Resource Conservation District
404 Orchard Avenue, Ukiah, CA 95482 (707) 468-9223

Or

http://mercd.org/wp-content/uploads/Handbook_for_Forest_Ranch&Rural_Roads.pdf

Appendix E: References

1. Humboldt County Web GIS. (2018, May). Humboldt County Planning and Building Department. Retrieved from <http://webgis.co.humboldt.ca.us/HCEGIS2.o/>
2. State of California, Department of Forestry and Fire Protection. (2018, January). *California Forest Practice Rules: Title 14, California code of regulations, chapters 4, 4.5 and 10 with the Z'Berg Nejedley Forest Practice Act, the Professional Foresters law, and the Registration of Professional Foresters Rules*. Sacramento, CA: The California Department of Forestry and Fire Protection.
3. California Natural Diversity Database (CNDDDB) Maps and Data. (2018). California Department of Fish and Wildlife. Retrieved from <https://www.wildlife.ca.gov/Data/CNDDDB/Maps-and-Data#43018408-cnddb-in-bios>
4. State of California, North Coast Regional Water Quality Control Board. (2015, August). *Order No. R1-2015-0023: Waiver of Waste Discharge Requirements and General Water Quality Certification*. Retrieved from https://www.waterboards.ca.gov/northcoast/board_decisions/adopted_orders/pdf/2015/15_0023_Cannabis_Order.pdf
5. State of California, State Water Resources Control Board. (2017, October). *Cannabis Cultivation Policy: Principles and Guidelines for Cannabis Cultivation*. Retrieved from https://www.waterboards.ca.gov/board_decisions/adopted_orders/resolutions/2017/final_cannabis_policy_with_att_a.pdf
6. State of California, State Water Resources Control Board. (2017, October). *Order No. WQ 2017-0023-DWQ: General Waste Discharge Requirements and Waiver of Waste Discharge Requirements for Discharges of Waste Associated with Cannabis Cultivation Activities*. Retrieved from https://www.waterboards.ca.gov/water_issues/programs/cannabis/docs/finaladoptedcango101717.pdf
7. State of California, California Department of Transportation, Division of Environmental Analysis, Stormwater Program. (2017, May). CTSW-RT-17-314.18.1: *Construction Site Best Management Practices (BMP) Manual*. Retrieved from <http://www.dot.ca.gov/hq/construc/stormwater/CSBMP-May-2017-Final.pdf>
8. Weaver, W.E., Weppner, E.M. and Hagans, D.K. (2015, April). *Handbook for Forest, Ranch and Rural Roads: A Guide for Planning, Designing, Constructing, Reconstructing, Upgrading, Maintaining and Closing Wildland Roads*. Ukiah, California: Mendocino County Conservation Resource District.



Appendix F: Water Diversion, Storage, and Use

SWRCB Cannabis Cultivation Waste Discharge Regulatory Program
Site Management Plan
 Water Diversion, Storage, and Use

Name: Eagles Nest Farms, LLC
APN: 220-191-029 & 220-191-027
Year: 2018

Total surface water diversion by source and month (gallons)**

Source	Jan	Feb	March	April	May	June	July	Aug	Sept	Oct	Nov	Dec	Total
Well (Cannabis)*													
Stream (Domestic)													

Water input to storage by source and month (gallons)

Source	Jan	Feb	March	April	May	June	July	Aug	Sept	Oct	Nov	Dec	Total
Well													
Stream (Domestic)													

Water use by source and month (gallons)

Use-Source	Jan	Feb	March	April	May	June	July	Aug	Sept	Oct	Nov	Dec	Total
Cannabis-Storage													
Cannabis-Diversion													
Domestic-Diversion													
Domestic-Storage													

*Not a surface water diversion

**Note: data is an approximation and is subject to change upon further analysis.



Appendix G: FERTILIZER, PESTICIDE, HERBICIDE, AND RODENTICIDE PRODUCT LIST AND RECORDS

Type	Brand	N-P-K	Total Nitrogen (lbs) Applied*	Total Phosphorous (lbs) Applied*
Growing Medium/Soil				
Fertilizer, Amendment, Additive				
Pesticide/Herbicide				

*Applied during _____.



Appendix G: FERTILIZER, PESTICIDE, HERBICIDE, AND RODENTICIDE PRODUCT LIST AND RECORDS

Type	Brand	N-P-K	Total Nitrogen (lbs) Applied*	Total Phosphorous (lbs) Applied*
Growing Medium/Soil	Aurora 707 Mix	N/A	N/A	N/A
	FoxFarm - Ocean Forest	N/A	N/A	N/A
	Down-to-Earth Green Sand	N/A	N/A	N/A
Fertilizer, Amendment, Additive	Roots Organics Big Worm	N/A	N/A	N/A
	Dr. Earth Premium Gold	4-4-4		
	Sparetime Supply Soluble Seaweed Powder	1-0-12		
	Rainbow Farms Quick Gro	4-3-2		
	Sparetime Supply Nitrogen Bat Guano	7-3-1		
	Stutzman Sup'r Green	3-2-2		
Pesticide/Herbicide	Safer Brand Insect Killing Soap	N/A	N/A	N/A
	Dyna Grow Neem Oil	N/A	N/A	N/A

*Applied during 2018.



Appendix H: Monthly BPTC Monitoring and Maintenance Records

Monitoring Data Sheet for SWRCB Cannabis Regulatory Program (BPTC Effectiveness Monitoring)

Inspector(s): _____

Date: _____

Owner: _____

APN: _____

Inspection Period (Circle) < Oct 15, < Dec 15, 0.5 in/day or 1 in/7 days

Other: _____

Map Point	BPTC	*Condition: G/M/R	Comment

* **G** - Good Condition (working as designed), **M** - Maintenance (needs maintenance to work properly), **R** - Replacement (needs to be reconstructed)



